

# CESSNA

MORE PEOPLE BUY AND  
FLY CESSNA AIRPLANES  
THAN ANY OTHER MAKE

## 1973

WORLD'S LARGEST PRO-  
DUCER OF GENERAL  
AVIATION AIRCRAFT  
SINCE 1956

# MODEL 182 AND SKYLANE



## OWNER'S MANUAL

# PERFORMANCE - SPECIFICATIONS

|  | Skylane * |
|--|-----------|
| GROSS WEIGHT . . . . .                         | 2950 lbs  |
| SPEED:   |           |
| Top Speed at Sea Level . . . . .               | 168 mph   |
| Cruise, 75% Power at 6500 ft . . . . .         | 160 mph   |
| RANGE:   |           |
| Cruise, 75% Power at 6500 ft . . . . .         | 690 mi    |
| 60 Gallons, No Reserve . . . . .               | 4.3 hrs   |
| 160 mph . . . . .                              | 160 mph   |
| Cruise, 75% Power at 6500 ft . . . . .         | 910 mi    |
| 79 Gallons, No Reserve . . . . .               | 5.7 hrs   |
| 160 mph . . . . .                              | 160 mph   |
| Optimum Range at 10,000 ft . . . . .           | 885 mi    |
| 60 Gallons, No Reserve . . . . .               | 7.7 hrs   |
| 115 mph . . . . .                              | 115 mph   |
| Optimum Range at 10,000 ft . . . . .           | 1160 mi   |
| 79 Gallons, No Reserve . . . . .               | 10.1 hrs  |
| 115 mph . . . . .                              | 115 mph   |
| RATE OF CLIMB AT SEA LEVEL . . . . .           | 890 fpm   |
| SERVICE CEILING . . . . .                      | 17,700 ft |
| TAKE-OFF:                                      |           |
| Ground Run . . . . .                           | 705 ft    |
| Total Distance Over 50-Foot Obstacle . . . . . | 1350 ft   |
| LANDING:                                       |           |
| Ground Roll . . . . .                          | 590 ft    |
| Total Distance Over 50-Foot Obstacle . . . . . | 1350 ft   |
| STALL SPEEDS:                                  |           |
| Flaps Up, Power Off . . . . .                  | 64 mph    |
| Flaps Down, Power Off . . . . .                | 57 mph    |
| EMPTY WEIGHT: (Approximate)                    |           |
| Skylane . . . . .                              | 1645 lbs  |
| Model 182 . . . . .                            | 1595 lbs  |
| USEFUL LOAD:                                   |           |
| Skylane . . . . .                              | 1305 lbs  |
| Model 182 . . . . .                            | 1355 lbs  |
| BAGGAGE:                                       |           |
| Forward Area "A" (Station 82 to 108) . . . . . | 120 lbs   |
| Aft Area "B" (Station 108 to 124) . . . . .    | 80 lbs    |
| WING LOADING: Pounds/Sq Foot . . . . .         | 16.9      |
| POWER LOADING: Pounds/HP . . . . .             | 12.8      |
| FUEL CAPACITY: Total                           |           |
| Standard Tanks . . . . .                       | 65 gal.   |
| Optional Long Range Tanks . . . . .            | 84 gal.   |
| OIL CAPACITY: Total . . . . .                  | 12 qts    |
| PROPELLER: Constant Speed (Diameter) . . . . . | 82 inches |
| ENGINE: Continental Engine . . . . .           | O-470-R   |
| 230 rated BHP at 2600 RPM . . . . .            |           |

NOTE: Performance data is shown for the Skylane which is 2 to 3 mph faster than a standard-equipped Model 182 (without speed fairings). There is a corresponding difference in range, while all other performance figures are the same for the 182 as shown for the Skylane.

\*This manual covers operation of the Model 182/Skylane which is certificated as Model 182P under FAA Type Certificate No. 3A13.

# SERVICING REQUIREMENTS

---

---

## FUEL:

AVIATION GRADE -- 80/87 Minimum Grade

CAPACITY EACH STANDARD TANK -- 32.5 Gallons

CAPACITY EACH LONG RANGE TANK -- 42.0 Gallons

(To ensure maximum fuel capacity during refueling, place the fuel selector valve handle in either "LEFT" or "RIGHT" position to prevent crossfeeding.)

## ENGINE OIL:

AVIATION GRADE -- SAE 50 Above 40°F.

SAE 10W30 or SAE 30 Below 40°F.

(Multi-viscosity oil with a range of SAE 10W30 is recommended for improved starting in cold weather. Detergent or dispersant oil, conforming to Continental Motors Specification MHS-24A, MUST BE USED.)

CAPACITY OF ENGINE SUMP -- 12 Quarts

(Do not operate on less than 9 quarts. To minimize loss of oil through breather, fill to 10 quart level for normal flights of less than 3 hours. For extended flight, fill to 12 quarts. The above quantities refer to oil dipstick level readings.)

## HYDRAULIC FLUID:

MIL-H-5606 Hydraulic Fluid

## OXYGEN:

AVIATOR'S BREATHING OXYGEN -- Spec. No. MIL-O-27210

MAXIMUM PRESSURE -- 1800 PSI at 70°F.

(Cylinder temperature stabilized after filling)

Refer to page 7-10 for filling pressures.

## TIRE PRESSURE:

MAIN WHEELS -- 42 PSI on 6.00 - 6, 6-Ply Rated Tires

NOSE WHEEL -- 49 PSI on 5.00 - 5, 6-Ply Rated Tire

## NOSE GEAR SHOCK STRUT:

Keep filled with hydraulic fluid and inflated with air to 55-60 PSI.

---

---

# CESSNA

"TAKE YOUR CESSNA HOME  
FOR SERVICE AT THE SIGN  
OF THE CESSNA SHIELD".



**CESSNA AIRCRAFT COMPANY**

WICHITA, KANSAS



# CONGRATULATIONS . . . . .

Welcome to the ranks of Cessna owners! Your Cessna has been designed and constructed to give you the most in performance, economy, and comfort. It is our desire that you will find flying it, either for business or pleasure, a pleasant and profitable experience.

This Owner's Manual has been prepared as a guide to help you get the most pleasure and utility from your Model 182/Skylane. It contains information about your Cessna's equipment, operating procedures, and performance; and suggestions for its servicing and care. We urge you to read it from cover to cover, and to refer to it frequently.

Our interest in your flying pleasure has not ceased with your purchase of a Cessna. World-wide, the Cessna Dealer Organization backed by the Cessna Service Department stands ready to serve you. The following services are offered by most Cessna Dealers:

**THE CESSNA WARRANTY** -- It is designed to provide you with the most comprehensive coverage possible:

- a. No exclusions
- b. Coverage includes parts and labor
- c. Available at Cessna Dealers world wide
- d. Best in the industry

Specific benefits and provisions of the warranty plus other important benefits for you are contained in your Customer Care Program book supplied with your aircraft. Warranty service is available to you at any authorized Cessna Dealer throughout the world upon presentation of your Customer Care Card which establishes your eligibility under the warranty.

**FACTORY TRAINED PERSONNEL** to provide you with courteous expert service.



**FACTORY APPROVED SERVICE EQUIPMENT** to provide you with the most efficient and accurate workmanship possible.

**A STOCK OF GENUINE CESSNA SERVICE PARTS** on hand when you need them.

**THE LATEST AUTHORITATIVE INFORMATION FOR SERVICING CESSNA AIRPLANES**, since Cessna Dealers have all of the Service Manuals and Parts Catalogs, kept current by Service Letters and Service News Letters, published by Cessna Aircraft Company.

We urge all Cessna owners to use the Cessna Dealer Organization to the fullest.



A current Cessna Dealer Directory accompanies your new airplane. The Directory is revised frequently, and a current copy can be obtained from your Cessna Dealer. Make your Directory one of your cross-country flight planning aids; a warm welcome awaits you at every Cessna Dealer.



\* Maximum height of airplane with nose gear depressed, all tires and nose strut properly inflated, and optional flashing beacon installed.

\*\* Wing span of airplane with optional strobe lights installed.

## PRINCIPAL DIMENSIONS



# TABLE OF CONTENTS

Page =

---

---

|             |  |      |
|-------------|--|------|
| SECTION I   | - OPERATING CHECK LIST .....                 | 1-1  |
| SECTION II  | - DESCRIPTION AND<br>OPERATING DETAILS ..... | 2-1  |
| SECTION III | - EMERGENCY PROCEDURES .....                 | 3-1  |
| SECTION IV  | - OPERATING LIMITATIONS .....                | 4-1  |
| SECTION V   | - CARE OF THE AIRPLANE .....                 | 5-1  |
|             | OWNER FOLLOW-UP SYSTEM .....                 | 5-12 |
| SECTION VI  | - OPERATIONAL DATA .....                     | 6-1  |
| SECTION VII | - OPTIONAL SYSTEMS .....                     | 7-1  |

---

This manual describes the operation and performance of both the Cessna Model 182 and the Cessna Skylane. Equipment described as "Optional" denotes that the subject equipment is optional on the Model 182. Much of this equipment is standard on the Skylane model.





# *Section I*

---

## OPERATING CHECK LIST


One of the first steps in obtaining the utmost performance, service, and flying enjoyment from your Cessna is to familiarize yourself with your airplane's equipment, systems, and controls. This can best be done by reviewing this equipment while sitting in the airplane. Those items whose function and operation are not obvious are covered in Section II.

Section I lists, in Pilot's Check List form, the steps necessary to operate your airplane efficiently and safely. It is not a check list in its true form as it is considerably longer, but it does cover briefly all of the points that you should know for a typical flight. An abbreviated check list covering the "Before Take-Off" and "Before Landing" phases of aircraft operation is provided on a plastic card and normally stowed in the map compartment. This abbreviated check list is a convenient reference of key items to be rechecked immediately prior to taxiing into position for take-off and before entering the final approach for landing.

The flight operational characteristics of your airplane are normal in all respects. There are no "unconventional" characteristics or operations that need to be mastered. All controls respond in the normal way within the entire range of operation. All airspeeds mentioned in Sections I, II, and III are indicated airspeeds. Corresponding calibrated airspeeds may be obtained from the Airspeed Correction Table in Section VI.

### **BEFORE ENTERING THE AIRPLANE.**

- (1) Make an exterior inspection in accordance with figure 1-1.



**EXTERIOR**

**INSPECTION**

**Note**

Visually check aircraft for general condition during walk-around inspection. In cold weather, remove even small accumulations of frost, ice or snow from wing, tail and control surfaces. Also, make sure that control surfaces contain no internal accumulations of ice or debris. If night flight is planned, check operation of all lights, and make sure a flashlight is available.

- ① a. Remove control wheel lock.
- b. Check ignition switch "OFF."
- c. Turn on master switch and check fuel quantity indicators; then turn master switch "OFF."
- d. Check fuel selector valve handle on "BOTH."
- e. Check baggage door for security. Lock with key if children are to occupy child's seat.

Figure

- ② a. Remove rudder gust lock, if installed.  
b. Disconnect tail tie-down.  
c. Check control surfaces for freedom of movement and security.
- ③ a. Check aileron for freedom of movement and security.
- ④ a. Disconnect wing tie-down.  
b. Check main wheel tire for proper inflation.  
c. Visually check fuel quantity; then check fuel filler cap secure and vent unobstructed.
- ⑤ a. Inspect flight instrument static source opening on side of fuselage for stoppage (both sides).  
b. Check propeller and spinner for nicks and security, and propeller for oil leaks.  
c. Check carburetor air filter for restrictions by dust or other foreign matter.  
d. Check nose wheel strut and tire for proper inflation.  
e. Disconnect tie-down rope.  
f. Check oil level. Do not operate with less than nine quarts. Fill to twelve quarts for extended flight.  
g. Before first flight of day and after each refueling, pull out strainer drain knob for about four seconds to clear fuel strainer of possible water and sediment. Check strainer drain closed. If water is observed, there is a possibility that the wing tank sumps contain water. Thus, the wing tank sump drain plugs and fuel selector valve drain plug should be removed to check for the presence of water.
- ⑥ a. Check main wheel tire for proper inflation.  
b. Visually check fuel quantity; then check fuel filler cap secure and vent unobstructed.
- ⑦ a. Remove pitot tube cover, if installed, and check pitot tube opening for stoppage.  
b. Check fuel tank vent opening for stoppage.  
c. Disconnect wing tie-down.
- ⑧ a. Check aileron for freedom of movement and security.

## **BEFORE STARTING THE ENGINE.**

- (1) Seats, Seat Belts and Shoulder Harnesses -- Adjust and lock.
- (2) Brakes -- Test and set.
- (3) Cowl Flaps -- "OPEN". (Move lever out of locking hole to reposition.)
- (4) Fuel Selector Valve Handle -- "BOTH".
- (5) Radios and Electrical Equipment -- "OFF".

## **STARTING ENGINE.**

- (1) Mixture -- Rich.
- (2) Carburetor Heat -- Cold.
- (3) Propeller -- High RPM.
- (4) Throttle -- Opened approximately one-half inch.
- (5) Primer -- As required.
- (6) Master Switch -- "ON".
- (7) Ignition Switch -- "START". Hold until engine fires, but not longer than 30 seconds (release when engine starts).

### **NOTE**

If engine has been overprimed, start with throttle open 1/4 to 1/2 full open. Reduce throttle to idle when engine fires.

### **NOTE**

After starting, check for oil pressure indication within 30 seconds in normal temperatures and 60 seconds in cold temperatures. If no indication appears, shut off engine and investigate.

## **BEFORE TAKE-OFF.**

- (1) Parking Brake -- Set.
- (2) Cowl Flaps -- Check full "OPEN".
- (3) Flight Controls -- Check for free and correct movement.
- (4) Fuel Selector Valve Handle -- "BOTH".
- (5) Elevator and Rudder Trim -- "TAKE-OFF" setting.
- (6) Throttle Setting -- 1700 RPM.
- (7) Engine Instruments and Ammeter -- Check.

- (8) Suction Gage -- Check in green arc (4.6 to 5.4 inches of mercury).
- (9) Magnetos -- Check (RPM drop should not exceed 150 RPM on either magneto or 50 RPM differential between magnetos).
- (10) Carburetor Heat -- Check operation.
- (11) Propeller -- Cycle from high to low RPM; return to high RPM (full in).
- (12) Flight Instruments and Radios -- Set.
- (13) Optional Autopilot or Wing Leveler -- "OFF".
- (14) Cabin Doors and Window -- Closed and locked.

## TAKE-OFF.

### NORMAL TAKE-OFF.

- (1) Wing Flaps -- 0° to 20°.
- (2) Carburetor Heat -- Cold.
- (3) Power -- Full throttle and 2600 RPM.
- (4) Elevator Control -- Raise nose wheel at 60 MPH.
- (5) Climb Speed -- 90 MPH until all obstacles are cleared, then set up climb speed as shown in "NORMAL CLIMB" check list.

### MAXIMUM PERFORMANCE TAKE-OFF.

- (1) Wing Flaps -- 20°.
- (2) Carburetor Heat -- Cold.
- (3) Brakes -- Apply.
- (4) Power -- Full throttle and 2600 RPM.
- (5) Brakes -- Release.
- (6) Elevator Control -- Maintain slightly tail-low attitude.
- (7) Climb Speed -- 60 MPH until all obstacles are cleared, then set up climb speed as shown in "MAXIMUM PERFORMANCE CLIMB" check list.
- (8) Wing Flaps -- Up after obstacles are cleared.

## ENROUTE CLIMB.

### NORMAL CLIMB.

- (1) Airspeed -- 100 to 110 MPH.
- (2) Power -- 23 inches and 2450 RPM.
- (3) Fuel Selector Valve Handle -- "BOTH."
- (4) Mixture -- Full rich (unless engine is rough due to excessively rich mixture).
- (5) Cowl Flaps -- Open as required.

### **MAXIMUM PERFORMANCE CLIMB.**

- (1) Airspeed -- 89 MPH (sea level) to 85 MPH (10,000 feet).
- (2) Power -- Full throttle and 2600 RPM.
- (3) Fuel Selector Valve Handle -- "BOTH."
- (4) Mixture -- Full rich (unless engine is rough).
- (5) Cowl Flaps -- Full "OPEN."

### **CRUISING.**

- (1) Engine Power -- 15 to 23 inches of manifold pressure and 2200 - 2450 RPM.
- (2) Cowl Flaps -- Open as required.
- (3) Elevator and Rudder Trim -- Adjust.
- (4) Mixture -- Lean.

### **LET-DOWN.**

- (1) Mixture -- Rich.
- (2) Power -- As desired.
- (3) Carburetor Heat -- Apply (if carburetor icing conditions exist).

### **BEFORE LANDING.**

- (1) Fuel Selector Valve Handle -- "BOTH."
- (2) Mixture -- Rich.
- (3) Propeller -- High RPM.
- (4) Cowl Flaps -- "CLOSED."
- (5) Carburetor Heat -- Apply before closing throttle.
- (6) Airspeed -- 80 to 90 MPH (flaps retracted).
- (7) Wing Flaps -- 0° to 40° (below 110 MPH).
- (8) Airspeed -- 70 to 80 MPH (flaps extended).
- (9) Elevator and Rudder Trim -- Adjust.

### **BALKED LANDING (GO-AROUND).**

- (1) Power -- Full throttle and 2600 RPM.

- (2) Carburetor Heat -- Cold.
- (3) Wing Flaps -- Retract to 20°.
- (4) Cowl Flaps -- "OPEN."
- (5) Upon reaching an airspeed of approximately 80 MPH, retract flaps slowly.

## **NORMAL LANDING.**

- (1) Touchdown -- Main wheels first.
- (2) Landing Roll -- Lower nose wheel gently.
- (3) Braking -- Minimum required.

## **AFTER LANDING.**

- (1) Cowl Flaps -- "OPEN."
- (2) Wing Flaps -- Retract.
- (3) Carburetor Heat -- Cold.

## **SECURING AIRCRAFT.**


- (1) Parking Brake -- Set.
- (2) Radios and Electrical Equipment -- "OFF".
- (3) Mixture -- Idle cut-off (pulled full out).

### **NOTE**

Do not open throttle as engine stops since this actuates the accelerator pump.

- (4) Ignition and Master Switch -- "OFF".
- (5) Control Lock -- Installed.

# INSTRUMENT PANEL



- |  |   |  |
|--|---|--|
| <ul style="list-style-type: none"> <li>1. Marker Beacon Indicator</li> <li>2. Lights and Switches (Opt.)</li> <li>3. Flight Instrument Group</li> <li>4. Autopilot Control Unit (Opt.)</li> <li>5. Map Light Switch and Light</li> <li>6. Transponder (Opt.)</li> <li>7. Radios (Opt.)</li> <li>8. Radio Selector Switches (Opt.)</li> <li>9. Rear View Mirror (Opt.)</li> <li>10. Radio Selector Switch Light</li> <li>11. Dimming Rheostat (Opt.)</li> <li>12. Manifold Pressure Gage</li> <li>13. Fuel Quantity Indicators and Ammeter</li> <li>14. Cylinder Head Temperature, Oil Temperature, and Oil Pressure Gages</li> </ul> | <ul style="list-style-type: none"> <li>15. Over-Voltage Warning Light</li> <li>16. Economy Mixture Indicator (Opt.)</li> <li>17. Carburetor Air Temperature Gage (Opt.)</li> <li>18. Flight Hour Recorder (Opt.)</li> <li>19. Optional Radio and Instrument Space</li> <li>20. Map Compartment</li> <li>21. Cabin Heat, Cabin Air and Defroster Control Knobs</li> <li>22. Cigar Lighter</li> <li>23. Tachometer</li> <li>24. Wing Flap Switch and Position Indicator</li> <li>25. Mixture Control Knob</li> <li>26. Propeller Control Knob</li> <li>27. Rudder Trim Control Wheel</li> </ul> | <ul style="list-style-type: none"> <li>28. Cowl Flap Control Handle</li> <li>29. Microphone (Opt.)</li> <li>30. Fuel Selector Valve Handle</li> <li>31. Elevator Trim Control Wheel</li> <li>32. Throttle</li> <li>33. Carburetor Heat Control Knob</li> <li>34. Electrical Switches</li> <li>35. Static Pressure Alternate Source Valve (Opt.)</li> <li>36. Parking Brake Handle</li> <li>37. Circuit Breakers</li> <li>38. Instrument and Radio Dial Light Rheostats</li> <li>39. Ignition/Starter Switch</li> <li>40. Engine Primer</li> <li>41. Phone Jack</li> <li>42. Master Switch</li> </ul> |
|--|---|--|

Figure 2-1.



# *Section II*

## DESCRIPTION AND OPERATING DETAILS

The following paragraphs describe the systems and equipment whose function and operation is not obvious when sitting in the airplane. This section also covers in somewhat greater detail some of the items listed in Check List form in Section I that require further explanation.

### **FUEL SYSTEM.**

Fuel is supplied to the engine from two tanks, one in each wing. With the fuel selector valve on "BOTH," the total usable fuel for all flight conditions is 60 gallons for the standard tanks and 79 gallons for optional long range tanks.

Fuel from each wing tank flows by gravity to a selector valve. Depending upon the setting of the selector valve, fuel from the left, right, or both tanks flows through a fuel strainer and carburetor to the engine induction system.

The fuel selector valve should be in the "BOTH" position for take-off, climb, landing, and maneuvers that involve prolonged slips or skids. Operation from either "LEFT" or "RIGHT" tank is reserved for cruising flight.

#### NOTE

When the fuel selector valve handle is in the "BOTH" position in cruising flight, unequal fuel flow from each tank may occur if the wings are not maintained exactly level. Resulting wing heaviness can be alleviated gradually by turning the selector valve handle to the tank in the "heavy" wing.

#### NOTE

It is not practical to measure the time required to consume all of the fuel in one tank, and, after switching to




Figure 2-2.

the opposite tank, expect an equal duration from the remaining fuel. The airspace in both fuel tanks is interconnected by a vent line (see figure 2-2) and, therefore, some sloshing of fuel between tanks can be expected when the tanks are nearly full and the wings are not level.

For fuel system servicing information, refer to Lubrication and Servicing Procedures in Section V.

## **ELECTRICAL SYSTEM.**

Electrical energy is supplied by a 14-volt, direct-current system powered by an engine-driven alternator (see figure 2-3). The 12-volt battery is located aft of the rear baggage compartment wall. Power is supplied to all electrical circuits through a split bus bar, one side containing electronic system circuits and the other side having general electrical system circuits. Both sides of the bus are on at all times except when either an external power source is connected or the starter switch is turned on; then a power contactor is automatically activated to open the circuit to the electronics bus. Isolating the electronic circuits in this manner prevents harmful transient voltages from damaging the transistors in the electronics equipment.

### **MASTER SWITCH.**

The master switch is a split-rocker type switch labeled "MASTER," and is "ON" in the up position and "OFF" in the down position. The right half of the switch, labeled "BAT," controls all electrical power to the airplane. The left half, labeled "ALT," controls the alternator.

Normally, both sides of the master switch should be used simultaneously; however, the "BAT" side of the switch could be turned "ON" separately to check equipment while on the ground. The "ALT" side of the switch, when placed in the "OFF" position, removes the alternator from the electrical system. With this switch in the "OFF" position, the entire electrical load is placed on the battery. Continued operation with the alternator switch "OFF" will reduce battery power low enough to open the battery contactor, remove power from the alternator field, and prevent alternator restart.

### **AMMETER.**

The ammeter indicates the flow of current, in amperes, from the al-

# ELECTRICAL SYSTEM

# SCHEMATIC




Figure 2-3.

ternator to the battery or from the battery to the aircraft electrical system. When the engine is operating and the master switch is "ON," the ammeter indicates the charging rate applied to the battery. In the event the alternator is not functioning or the electrical load exceeds the output of the alternator, the ammeter indicates the discharge rate of the battery.

### **OVER-VOLTAGE SENSOR AND WARNING LIGHT.**

The aircraft is equipped with an automatic over-voltage protection system consisting of an over-voltage sensor behind the instrument panel and a red warning light, labeled "HIGH VOLTAGE", below the engine instrument cluster.

In the event an over-voltage condition occurs, the over-voltage sensor automatically removes alternator field current and shuts down the alternator. The red warning light will then turn on, indicating to the pilot that the alternator is not operating and the aircraft battery is supplying all electrical power.

The over-voltage sensor may be reset by turning the master switch off and back on again. If the warning light does not illuminate, normal alternator charging has resumed; however, if the light does illuminate again, a malfunction has occurred, and the flight should be terminated as soon as practical.

The over-voltage warning light may be tested by momentarily turning off the "ALT" portion of the master switch and leaving the "BAT" portion turned on.

### **CIRCUIT BREAKERS AND FUSES.**

Most of the electrical circuits in the airplane are protected by "push-to-reset" circuit breakers mounted on the instrument panel. Exceptions to this are the battery contactor closing (external power) circuit, and the optional clock and flight hour recorder circuits which have fuses mounted near the battery. Also, the cigar lighter is protected by a manually-reset type circuit breaker mounted directly on the back of the lighter behind the instrument panel.

When more than one radio is installed, the radio transmitter relay (which is a part of the radio installation) is protected by the navigation lights circuit breaker labeled "NAV LIGHTS." It is important to remember that any malfunction in the navigation lights system which causes the circuit breaker to open will de-activate both the navigation lights and the

transmitter relay. In this event, the navigation light switch should be turned off to isolate the circuit; then reset the circuit breaker to re-activate the transmitter relay and permit its usage. Do not turn on the navigation light switch until the malfunction has been corrected.

## **LIGHTING EQUIPMENT.**

### **EXTERIOR LIGHTING.**

Conventional navigation lights are located in the wing tips and tail stinger. Two landing lights are installed in the cowl nose cap. When taxi lighting is selected, the left cowl light illuminates separately. Depressing the adjacent landing light switch causes both lights to illuminate and serve as landing lights. Optional lighting includes a flashing beacon which mounts on the top of the vertical fin, two strobe lights (one in each wing tip), and two courtesy lights (one under each wing just outboard of the cabin door). All exterior lights except the courtesy lights are controlled by rocker-type switches located on the left switch and control panel. The courtesy lights are operated by a switch on the aft side of the left rear door post.

The flashing beacon should not be used when flying through clouds or overcast; the flashing light reflected from water droplets or particles in the atmosphere, particularly at night, can produce vertigo and loss of orientation.

The two high intensity strobe lights will enhance anti-collision protection. However, the lights should be turned off when taxiing in the vicinity of other aircraft, or during flight through clouds, fog or haze.

### **INTERIOR LIGHTING.**

Instrument and control panel lighting is provided by electroluminescent lighting, flood lighting, optional post lighting and integral lighting. Two concentric rheostat control knobs labeled "LWR PANEL, ENG-RADIO," and a rheostat control knob labeled "INSTRUMENTS" control the intensity of instrument and control panel lighting. A rocker-type switch labeled "POST-FLOOD LIGHTS" is used to select either standard flood lighting or optional post lighting. These controls are located on the left switch and control panel.

Switches and controls on the lower part of the instrument panel are

lighted by electroluminescent panels which do not require light bulbs for illumination. To operate this lighting, turn on the "NAV LIGHTS" switch and adjust light intensity with the inner control knob labeled "LWR PANEL."

Instrument panel flood lighting consists of four lights located in the glare shield above the instrument panel and two lights in the overhead console. To use flood lighting, place the "POST-FLOOD LIGHTS" selector switch in the "FLOOD LIGHTS" position and adjust light intensity with the "INSTRUMENTS" control knob.

The instrument panel may be equipped with optional post lights which are mounted at the edge of each instrument or control and provide direct lighting. The lights are operated by placing the "POST-FLOOD LIGHTS" selector switch in the "POST" position and adjusting intensity with the "INSTRUMENTS" control knob. Switching to post lights will automatically turn off flood lighting.

The magnetic compass, engine instrument cluster, radios and radio selector switches have integral lighting and operate independently of post or flood lighting. Compass light intensity is controlled by the "INSTRUMENTS" control knob. Integral lighting in the engine instrument cluster and radios is controlled by the "ENG-RADIO" control knob. For information concerning radio selector switch lighting, refer to Section VII.

The control pedestal and optional overhead oxygen console are lighted separately by post lights. This lighting is controlled by the "ENG-RADIO" control knob.

Map lighting may be provided by three different sources: standard overhead console map lights, a standard glare shield mounted map light, and an optional control wheel map light. The console map lights operate in conjunction with instrument panel flood lighting and consist of two additional openings just aft of the overhead flood light openings. These openings have sliding covers controlled by small round knobs. To use the map lights, slide the covers open by moving the two knobs toward each other. Close the covers when the map lights are no longer required. A map light, mounted in the lower surface of the glare shield, is used for illuminating approach plates or other charts when using a control wheel mounted approach plate clip. The map light switch, labeled "MAP LIGHT," is located adjacent to the light. To use the light, turn on the "MAP LIGHT" switch and adjust intensity with the "INSTRUMENTS" control knob. The optional map light mounted on the bottom of the pilot's control wheel illuminates the lower portion of the cabin in front of the pilot, and is used when checking maps and other flight data during night operation. To op-

erate the light, turn on the "NAV LIGHT" switch and adjust map light intensity with the rheostat control knob on the back of the control wheel pad on the right side.

A dome light is mounted in the ceiling of the rear cabin area as an aid to loading of passengers during night operations. A slide switch adjacent to the light turns the light on and off.

## **CABIN HEATING, VENTILATING AND DEFROSTING SYSTEM.**

The temperature and volume of airflow into the cabin can be regulated to any degree desired by manipulation of the push-pull "CABIN HEAT" and "CABIN AIR" knobs. Both control knobs are the double-button type with friction locks to permit intermediate settings.

### **NOTE**

For improved partial heating on mild days, pull out the "CABIN AIR" knob slightly when the "CABIN HEAT" knob is out. This action increases the airflow through the system, increasing efficiency, and blends cool outside air with the exhaust manifold heated air, thus eliminating the possibility of overheating the system ducting.

The rotary type "DEFROST" knob regulates the airflow for windshield defrosting.

Front cabin heat and ventilating air is supplied by outlet holes spaced across a cabin manifold just forward of the pilot's and copilot's feet. Rear cabin heat and air are supplied by two ducts from the manifold, one extending down each side of the cabin to an outlet at the front door post at floor level. Windshield defrost air is also supplied by a duct leading from the cabin manifold.

Separate adjustable ventilators supply additional air; one near each upper corner of the windshield supplies air for the pilot and copilot, and two optional ventilators in the rear cabin ceiling supply air to the rear seat passengers.



## SHOULDER HARNESES.

Shoulder harnesses are provided as standard equipment for the pilot and front seat passenger, and as optional equipment for the rear seat passengers.

Each front seat harness is attached to a rear door post just above window line and is stowed above the cabin door. When stowed, the harness is held in place by two retaining clips, one above the door and one at the top of the forward door post. The optional rear seat shoulder harnesses are attached adjacent to the lower corners of the rear window. Each rear seat harness is stowed behind a retaining clip located at the bottom edge of the aft side window.

To use the front and rear seat shoulder harnesses, fasten and adjust the seat belt first. Remove the harness from the stowed position, and lengthen as required by pulling on the end of the harness and the narrow release strap. Snap the harness metal stud firmly into the retaining slot adjacent to the seat belt buckle. Then adjust to length by pulling down on the free end of the harness. A properly adjusted harness will permit the occupant to lean forward enough to sit completely erect but is tight enough to prevent excessive forward movement and contact with objects during sudden deceleration. Also, the pilot will want the freedom to reach all controls easily.

Releasing and removing the shoulder harness is accomplished by pulling upward on the narrow release strap and removing the harness stud from the slot in the seat belt buckle. In an emergency, the shoulder harness may be removed by releasing the seat belt first, and then pulling the harness over the head by pulling up on the release strap.

## STARTING ENGINE.

Ordinarily the engine starts easily with one or two strokes of the primer in warm temperatures to six strokes in cold weather with the throttle open approximately 1/2 inch. In extremely cold temperatures it may be necessary to continue priming while cranking. Weak intermittent firing followed by puffs of black smoke from the exhaust stack indicate overpriming or flooding. Excess fuel can be cleared from the combustion chambers by the following procedure: Set the mixture control full lean and the throttle full open; then crank the engine through several revolutions with the starter. Repeat the starting procedure without any additional priming.

If the engine is underprimed (most likely in cold weather with a cold engine) it will not fire at all. Additional priming will be necessary for the next starting attempt. As soon as the cylinders begin to fire, open the throttle slightly to keep it running.

If prolonged cranking is necessary, allow the starter motor to cool at frequent intervals, since excessive heat may damage the armature.

## **TAXIING.**

The carburetor heat knob should be pushed full in during all ground operations unless heat is absolutely necessary for smooth engine operation. When the knob is pulled out to the heat position, air entering the engine is not filtered.

Taxiing over loose gravel or cinders should be done at low engine speed to avoid abrasion and stone damage to the propeller tips. Refer to figure 2-4 for additional taxiing instructions.

## **BEFORE TAKE-OFF.**

### **WARM-UP.**


Since the engine is closely cowled for efficient in-flight cooling, precautions should be taken to avoid overheating on the ground. Full throttle checks on the ground are not recommended unless the pilot has good reason to suspect that the engine is not turning up properly.

### **MAGNETO CHECK.**

The magneto check should be made at 1700 RPM as follows. Move ignition switch first to "R" position, and note RPM. Next move switch back to "BOTH" to clear the other set of plugs. Then move switch to "L" position, note RPM and return the switch to the "BOTH" position. RPM drop should not exceed 150 RPM on either magneto or show greater than 50 RPM differential between magnetos. If there is a doubt concerning operation of the ignition system, RPM checks at higher engine speeds will usually confirm whether a deficiency exists.

An absence of RPM drop may be an indication of faulty grounding of one side of the ignition system or should be cause for suspicion that the magneto timing is set in advance of the setting specified.

## TAXIING DIAGRAM



### CODE

WIND DIRECTION



### NOTE

Strong quartering tail winds require caution. Avoid sudden bursts of the throttle and sharp braking when the airplane is in this attitude. Use the steerable nose wheel and rudder to maintain direction.

Figure 2-4.

## ALTERNATOR CHECK.

Prior to flights where verification of proper alternator and voltage regulator operation is essential (such as night or instrument flights), a positive verification can be made by loading the electrical system momentarily (3 to 5 seconds) with the landing light during the engine runup (1700 RPM). The ammeter will remain within a needle width of zero if the alternator and voltage regulator are operating properly.

## TAKE-OFF.

It is important to check full-throttle engine operation early in the take-off run. Any signs of rough engine operation or sluggish engine acceleration is good cause for discontinuing the take-off.

Full throttle runups over loose gravel are especially harmful to propeller tips. When take-offs must be made over a gravel surface, it is very important that the throttle be advanced slowly. This allows the airplane to start rolling before high RPM is developed, and the gravel will be blown back of the propeller rather than pulled into it.

Most engine wear occurs from improper operation before the engine is up to normal operating temperatures, and operating at high powers and RPM's. For this reason the use of maximum power for take-off climb should be limited to that absolutely necessary for safety. Whenever possible, reduce take-off power to normal climb power.

Normal take-offs are accomplished with wing flaps  $0^{\circ}$  to  $20^{\circ}$ , cowl flaps open, full throttle, and 2600 RPM. Reduce power to 23 inches of manifold pressure and 2450 RPM as soon as practical to minimize engine wear.

Using  $20^{\circ}$  wing flaps reduces the ground run and total distance over the obstacle by approximately 20 per cent. Soft field take-offs are performed with  $20^{\circ}$  flaps by lifting the airplane off the ground as soon as practical in a slightly tail-low attitude. However, the airplane should be leveled off immediately to accelerate to a safe climb speed.

If  $20^{\circ}$  wing flaps are used for take-off, they should be left down until all obstacles are cleared. To clear an obstacle with wing flaps 20 degrees, an obstacle clearance speed of 60 MPH should be used. If no obstructions are ahead, a best "flaps up" rate-of-climb speed

of 89 MPH would be most efficient. These speeds vary slightly with altitude, but they are close enough for average field elevations. Flap deflections greater than 20° are not recommended at any time for take-off.

Take-offs into strong crosswinds normally are performed with the minimum flap setting necessary for the field length, to minimize the drift angle immediately after take-off. The airplane is accelerated to a speed slightly higher than normal, then pulled off abruptly to prevent possible settling back to the runway while drifting. When clear of the ground, make a coordinated turn into the wind to correct for drift.

## **ENROUTE CLIMB.**

A cruising climb at 23 inches of manifold pressure, 2450 RPM (approximately 75% power) and 100 to 120 MPH is recommended to save time and fuel for the overall trip. In addition, this type of climb provides better engine cooling, less engine wear, and more passenger comfort due to lower noise level.

If it is necessary to climb rapidly to clear mountains or reach favorable winds at high altitudes, the best rate-of-climb speed should be used with maximum power. This speed is 89 MPH at sea level, decreasing 2 MPH for each 5000 feet above sea level.

If an obstruction ahead requires a steep climb angle, the airplane should be flown at an obstacle clearance speed of approximately 70 MPH with flaps up and maximum power.

## **CRUISE.**

Normal cruising is done between 65% and 75% power. The power settings required to obtain these powers at various altitudes and outside air temperatures can be determined by using your Cessna Power Computer or the OPERATIONAL DATA, Section VI.

The Maximum Cruise Speed Performance table (figure 2-5) shows that cruising can be done most efficiently at higher altitudes because very nearly the same cruising speed can be maintained at much less power.

## MAXIMUM CRUISE SPEED PERFORMANCE

| ALTITUDE | % POWER | TRUE AIRSPEED | RANGE<br>(STD. TANKS) |
|----------|---------|---------------|-----------------------|
| 6500     | 75      | 160           | 690                   |
| 8000     | 70      | 158           | 730                   |
| 10,000   | 65      | 156           | 775                   |

Figure 2-5.

For a given throttle setting, select the lowest engine RPM in the green arc range that will give smooth engine operation.

The cowl flaps should be adjusted to maintain the cylinder head temperature at approximately two thirds of the normal operating (green arc) range to assure prolonged engine life.

To achieve the range figures shown in Section VI, the mixture should be leaned as follows: pull mixture control out until engine becomes rough; then enrich mixture slightly from this point. Any change in altitude, power, or carburetor heat will require a change in the lean mixture setting.

Application of full carburetor heat may enrich the mixture to the point of engine roughness. To avoid this, lean the mixture as instructed in the preceding paragraph.

The use of full carburetor heat is recommended during flight in very heavy rain to avoid the possibility of engine stoppage due to excessive water ingestion. The mixture setting should be readjusted for smoothest operation.

### STALLS.

The stall characteristics are conventional and aural warning is provided by a stall warning horn which sounds between 5 and 10 MPH above the stall in all configurations.

Power-off stall speeds at maximum gross weight and aft c.g. posi-

tion are presented in figure 6-2 as calibrated airspeeds since indicated airspeeds are unreliable near the stall.

## **SPINS.**

Intentional spins are prohibited in this airplane. Should an inadvertent spin occur, the following recovery technique should be used.

- (1) Retard throttle to idle position.
- (2) Apply full rudder opposite to the direction of rotation.
- (3) After one-fourth turn, move the control wheel forward of neutral in a brisk motion.
- (4) As rotation stops, neutralize rudder, and make a smooth recovery from the resulting dive.

## **LANDING.**

### **NORMAL LANDING.**

Landings should be made on the main wheels first to reduce the landing speed and the subsequent need for braking in the landing roll. The nose wheel is lowered gently to the runway after the speed has diminished to avoid unnecessary nose gear load. This procedure is especially important in rough field landings.

### **SHORT FIELD LANDING.**

For short field landings, make a power-off approach at 69 MPH with 40° flaps and land on the main wheels first. Immediately after touchdown, lower the nose gear to the ground and apply heavy braking as required. For maximum brake effectiveness after all three wheels are on the ground, retract the flaps, hold full nose up elevator and apply maximum possible brake pressure without sliding the tires.

### **CROSSWIND LANDING.**

When landing in a strong crosswind, use the minimum flap setting required for the field length. Although the crab or combination method of drift correction may be used, the wing-low method gives the best control. After touchdown, hold a straight course with the steerable nose wheel and occasional braking if necessary.

## **BALKED LANDING (GO-AROUND).**

In a balked landing (go-around) climb, the wing flap setting should be reduced to 20° immediately after full power is applied. After all obstacles are cleared and a safe altitude and airspeed are obtained, the wing flaps should be retracted.

## **COLD WEATHER OPERATION.**

### **STARTING.**

Prior to starting on a cold morning, it is advisable to pull the propeller through several times by hand to "break loose" or "limber" the oil, thus conserving battery energy.

#### **NOTE**

When pulling the propeller through by hand, treat it as if the ignition switch is turned on. A loose or broken ground wire on either magneto could cause the engine to fire.

In extremely cold (0°F and lower) weather, the use of an external preheater (for both the engine and battery) and an external power source is recommended whenever possible to obtain positive starting and to reduce wear and abuse to the engine and the electrical system. Pre-heat will thaw the oil trapped in the oil cooler, which probably will be congealed prior to starting in extremely cold temperatures. When using an external power source, the position of the master switch is important. Refer to Section VII, paragraph Ground Service Plug Receptacle, for operating details.

Cold weather starting procedures are as follows:

#### With Preheat:

(1) With ignition switch "OFF", mixture full rich, and throttle open 1/2", prime the engine four to eight strokes as the propeller is being turned over by hand.

#### **NOTE**

Use heavy strokes of the primer for best atomization of fuel. After priming, push the primer all the way in and



turn to the locked position to avoid the possibility of the engine drawing fuel through the primer.

- (2) Clear propeller.
- (3) Turn master switch "ON."
- (4) Turn ignition switch to "START."
- (5) Pull carburetor heat on after engine has started, and leave on until the engine is running smoothly.

Without Preheat:

- (1) Prime the engine six to eight strokes while the propeller is being turned by hand with mixture full rich and throttle open 1/2". Leave the primer charged and ready for stroke.
- (2) Clear propeller.
- (3) Turn master switch "ON".
- (4) Turn ignition switch to "START".
- (5) Pump throttle rapidly to full open twice. Return to 1/2" open position.
- (6) Release ignition switch to "BOTH" when engine starts.
- (7) Continue to prime the engine until it is running smoothly, or alternately, pump the throttle rapidly over the first 1/4 of total travel.
- (8) Oil pressure -- Check.
- (9) Pull carburetor heat on after engine has started. Leave on until the engine is running smoothly.
- (10) Lock primer.

**NOTE**

If the engine does not start during the first few attempts, or if engine firing diminishes in strength, it is probable that the spark plugs have been frosted over. Preheat must be used before another start is attempted.

**IMPORTANT**

Excessive priming and pumping throttle may cause raw fuel to accumulate in the intake air duct, creating a fire hazard in the event of a backfire. If this occurs, maintain a cranking action to suck flames into the engine. An outside attendant with a fire extinguisher is advised for cold starts without preheat.

## OPERATION.

During cold weather operations, no indication will be apparent on the oil temperature gage prior to take-off if outside air temperatures are very cold. After a suitable warm-up period (2 to 5 minutes at 1000 RPM), accelerate the engine several times to higher engine RPM. If the engine accelerates smoothly and the oil pressure remains normal and steady, the airplane is ready for take-off.

Rough engine operation in cold weather can be caused by a combination of an inherently leaner mixture due to the dense air and poor vaporization and distribution of the fuel-air mixture to the cylinders. The effects of these conditions are especially noticeable during operation on one magneto in ground checks where only one spark plug fires in each cylinder.

For optimum operation of the engine in cold weather, the appropriate use of carburetor heat is recommended. The following procedures are indicated as a guideline:

- (1) Use carburetor heat during engine warm-up and ground check. Full carburetor heat may be required for temperatures below 10°F, whereas partial heat could be used in temperatures between 10°F and 40°F.
- (2) Use the minimum carburetor heat required for smooth operation in take-off, climb, and cruise.

### NOTE

When operating in sub-zero temperatures, care should be exercised when using partial carburetor heat to avoid icing. Partial heat may raise the carburetor air temperature to the 32° to 70°F range where icing is critical under certain atmospheric conditions.

- (3) If the aircraft is equipped with a carburetor air temperature gage, it can be used as a reference in maintaining carburetor air temperature at or slightly above the top of the yellow arc by application of carburetor heat.
- (4) Select relatively high manifold pressure and RPM settings for optimum mixture distribution, and avoid excessive manual leaning in cruising flight.
- (5) Avoid sudden throttle movements during ground and flight operation.

Refer to Section VII for discussion of additional cold weather equipment.

## **HOT WEATHER OPERATION.**

The general warm temperature starting information on page 2-9 is appropriate. Avoid prolonged engine operation on the ground.



# *Section III*

---

## **EMERGENCY PROCEDURES**

Emergencies caused by aircraft or engine malfunctions are extremely rare if proper pre-flight inspections and maintenance are practiced. Enroute weather emergencies can be minimized or eliminated by careful flight planning and good judgement when unexpected weather is encountered. However, should an emergency arise, the basic guidelines described in this section should be considered and applied as necessary to correct the problem.

### **ELECTRICAL POWER SUPPLY SYSTEM MALFUNCTIONS.**

Malfunctions in the electrical power supply system can be detected by periodic monitoring of the ammeter and over-voltage warning light; however, the cause of these malfunctions is usually difficult to determine. A broken alternator drive belt or wiring is most likely the cause of alternator failures, although other factors could cause the problem. A damaged or improperly adjusted voltage regulator can also cause malfunctions. Problems of this nature constitute an electrical emergency and should be dealt with immediately. Electrical power malfunctions usually fall into two categories: excessive rate of charge and insufficient rate of charge. The paragraphs below describe the recommended remedy for each situation.

#### **EXCESSIVE RATE OF CHARGE.**

After engine starting and heavy electrical usage at low engine speeds (such as extended taxiing) the battery condition will be low enough to accept above normal charging during the initial part of a flight. However, after thirty minutes of cruising flight, the ammeter should be indicating less than two needle widths of charging current. If the charging rate were to remain above this value on a long flight, the battery would over-heat and evaporate the electrolyte at an excessive rate. Electronic components in the electrical system could be adversely affected by higher than normal voltage if a faulty voltage regulator setting is causing the overcharging. To preclude these possibilities, an over-voltage sensor will automatically shut down the alternator and the over-voltage warning

light will illuminate if the charge voltage reaches approximately 16 volts. Assuming that the malfunction was only momentary, an attempt should be made to reactivate the alternator system. To do this, turn both sides of the master switch off and then on again. If the problem no longer exists, normal alternator charging will resume and the warning light will go off. If the light comes on again, a malfunction is confirmed. In this event, the flight should be terminated and/or the current drain on the battery minimized because the battery can supply the electrical system for only a limited period of time. If the emergency occurs at night, power must be conserved for later use of the landing lights and flaps during landing.

### **INSUFFICIENT RATE OF CHARGE.**

If the ammeter indicates a continuous discharge rate in flight, the alternator is not supplying power to the system and should be shut down since the alternator field circuit may be placing an unnecessary load on the system. All non-essential equipment should be turned "OFF" and the flight terminated as soon as practical.

## **ROUGH ENGINE OPERATION OR LOSS OF POWER.**

### **SPARK PLUG FOULING.**

A slight engine roughness in flight may be caused by one or more spark plugs becoming fouled by carbon or lead deposits. This may be verified by turning the ignition switch momentarily from "BOTH" to either the "L" or "R" position. An obvious power loss in single ignition operation is evidence of spark plug or magneto trouble. Assuming that spark plugs are the more likely cause, lean the mixture to the normal lean setting for cruising flight. If the problem does not clear up in several minutes, determine if a richer mixture setting will produce smoother operation. If not, proceed to the nearest airport for repairs using the "BOTH" position of the ignition switch unless extreme roughness dictates the use of a single-ignition position.

### **MAGNETO MALFUNCTION.**

A sudden engine roughness or misfiring is usually evidence of magneto problems. Switching from "BOTH" to either the "L" or "R" ignition switch position will identify which magneto is malfunctioning. Select different power settings and enrichen the mixture to determine if continued operation on "BOTH" magnetos is practicable. If not, switch to the good magneto and proceed to the nearest airport for repairs.

## **LOW OIL PRESSURE.**

If low oil pressure is accompanied by normal oil temperature, there is a possibility the oil pressure gage or relief valve is malfunctioning. A leak in the line to the gage is not necessarily cause for an immediate precautionary landing because an orifice in this line will prevent a sudden loss of oil from the engine sump. However, a landing at the nearest airport would be advisable to inspect the source of trouble.

If a total loss of oil pressure is accompanied by a rise in oil temperature, there is reason to suspect an engine failure is imminent. Reduce engine power immediately and select a suitable forced landing field. Leave the engine running at low power during the approach, using only the minimum power required to reach the desired touchdown spot.

## **FORCED LANDINGS.**

### **PRECAUTIONARY LANDING WITH ENGINE POWER.**

Before attempting an "off airport" landing, one should drag the landing area at a safe but low altitude to inspect the terrain for obstructions and surface conditions, proceeding as follows:

- (1) Perform "before landing" check.
- (2) Drag over selected field with flaps 20° and 75 MPH airspeed, noting the preferred area for touchdown for the next landing approach. Then retract flaps upon reaching a safe altitude and airspeed.
- (3) On downwind leg, turn off all switches except the ignition and master switches.
- (4) Approach with flaps 40° at 75 MPH.
- (5) Unlatch cabin doors prior to final approach.
- (6) Before touchdown, turn ignition and master switches "OFF."
- (7) Land in a slightly tail-low attitude.

### **EMERGENCY LANDING WITHOUT ENGINE POWER.**

If an engine stoppage occurs, establish a flaps-up glide at 80 MPH. If time permits, attempt to restart the engine by checking for fuel quantity, proper fuel selector valve position, and mixture control setting. Also check that engine primer is full in and locked and ignition switch is properly positioned.

If all attempts to restart the engine fail, and a forced landing is imminent, select a suitable field and prepare for the landing as follows:

- (1) Pull mixture control to idle cut-off position.
- (2) Turn fuel selector valve handle "OFF".
- (3) Turn all switches "OFF" except master switch.
- (4) Approach at 80 MPH.
- (5) Extend wing flaps as necessary within gliding distance of field.
- (6) Turn master switch "OFF."
- (7) Unlatch cabin doors prior to final approach.
- (8) Land in a slightly tail-low attitude.
- (9) Apply heavy braking while holding full up elevator.

## DITCHING.

Prepare for ditching by securing or jettisoning heavy objects located in the baggage area, and collect folded coats or cushions for protection of occupant's face at touchdown. Transmit Mayday message on 121.5 MHz. giving location and intentions.

- (1) Plan approach into wind if winds are high and seas are heavy. With heavy swells and light wind, land parallel to swells.
- (2) Approach with flaps 40° and sufficient power for a 300 ft./min. rate of descent at 70 MPH.
- (3) Unlatch the cabin doors.
- (4) Maintain a continuous descent until touchdown in level attitude. Avoid a landing flare because of difficulty in judging airplane height over a water surface.
- (5) Place folded coat or cushion in front of face at time of touchdown.
- (6) Evacuate airplane through cabin doors. If necessary, open vent windows to flood cabin compartment for equalizing pressure so that door can be opened.
- (7) Inflate life vests and raft (if available) after evacuation of cabin. The aircraft can not be depended on for floatation for ~~more than~~ a few minutes.

## DISORIENTATION IN CLOUDS.

When flying in marginal weather, the pilot should make sure that the



Wing Leveler (if installed) control knob is "ON." However, if the airplane is not equipped with this device or gyro horizon and directional gyro instruments, the pilot will have to rely on the turn coordinator (or turn and bank indicator) if he inadvertently flies into clouds. The following instructions assume that only one of the latter two instruments is available.

### **EXECUTING A 180° TURN IN CLOUDS.**

Upon entering the clouds, an immediate plan should be made to turn back as follows:

- (1) Note the time of the minute hand and observe the position of the sweep second hand on the clock.
- (2) When the sweep second hand indicates the nearest half-minute, initiate a standard rate left turn, holding the turn coordinator symbolic airplane wing opposite the lower left index mark for 60 seconds. Then roll back to level flight by leveling the miniature airplane.
- (3) Check accuracy of the turn by observing the compass heading which should be the reciprocal of the original heading.
- (4) If necessary, adjust heading primarily with skidding motions rather than rolling motions so that the compass will read more accurately.
- (5) Maintain altitude and airspeed by cautious application of elevator control. Avoid overcontrolling by keeping the hands off the control wheel and steering only with rudder.

### **EMERGENCY LET-DOWNS THROUGH CLOUDS.**

If possible, obtain radio clearance for an emergency descent through clouds. To guard against a spiral dive, choose an easterly or westerly heading to minimize compass card swings due to changing bank angles. In addition, keep hands off the control wheel and steer a straight course with rudder control by monitoring the turn coordinator. Occasionally check the compass heading and make minor corrections to hold an approximate course. Before descending into the clouds, set up a stabilized let-down condition as follows:

- (1) Apply full rich mixture.
- (2) Use full carburetor heat.
- (3) Reduce power to set up a 500 to 800 ft./min. rate of descent.
- (4) Adjust the elevator trim tab for a stabilized descent at 90 MPH.
- (5) Keep hands off the control wheel.
- (6) Monitor turn coordinator and make corrections by rudder alone.
- (7) Adjust rudder trim to relieve unbalanced rudder force, if present.

- (8) Check trend of compass card movement and make cautious corrections with rudder to stop the turn.
- (9) Upon breaking out of clouds, resume normal cruising flight.

## **RECOVERY FROM A SPIRAL DIVE.**

If a spiral is encountered, proceed as follows:

- (1) Close the throttle.
- (2) Stop the turn by using coordinated aileron and rudder control to align the symbolic airplane in the turn coordinator with the horizon reference line.
- (3) Cautiously apply elevator back pressure to slowly reduce the indicated airspeed to 90 MPH.
- (4) Adjust the elevator trim control to maintain a 90 MPH glide.
- (5) Keep hands off the control wheel, using rudder control to hold a straight heading. Use rudder trim to relieve unbalanced rudder force, if present.
- (6) Apply carburetor heat.
- (7) Clear engine occasionally, but avoid using enough power to disturb the trimmed glide.
- (8) Upon breaking out of clouds, apply normal cruising power and resume flight.

## **FIRES.**

### **ENGINE FIRE DURING START ON GROUND.**

Improper starting procedures such as pumping the throttle during a difficult cold weather start can cause a backfire which could ignite fuel that has accumulated in the intake duct. In this event, proceed as follows:

- (1) Continue cranking in an attempt to get a start which would suck the flames and accumulated fuel through the carburetor and into the engine.
- (2) If the start is successful, run the engine at 1700 RPM for a few minutes before shutting it down to inspect the damage.
- (3) If engine start is unsuccessful, continue cranking for two or three minutes with throttle full open while ground attendants obtain fire extinguishers.

- (4) When ready to extinguish fire, release the starter switch and turn off master switch, ignition switch, and fuel selector valve.
- (5) Smother flames with fire extinguisher, seat cushion, wool blanket, or loose dirt.
- (6) Make a thorough inspection of fire damage, and repair or replace damaged components before conducting another flight.

### **ENGINE FIRE IN FLIGHT.**

Although engine fires are extremely rare in flight, the following steps should be taken if one is encountered:

- (1) Pull mixture control to idle cut-off.
- (2) Turn fuel selector valve handle "OFF."
- (3) Turn master switch "OFF."
- (4) Establish a 100 MPH glide.
- (5) Close cabin heat and cabin air controls.
- (6) Select a field suitable for a forced landing.
- (7) If fire is not extinguished, increase glide speed in an attempt to find an airspeed that will provide an incombustible mixture.
- (8) Execute a forced landing as described in paragraph Emergency Landing Without Engine Power. Do not attempt to restart the engine.

### **ELECTRICAL FIRE IN FLIGHT.**

The initial indication of an electrical fire is the odor of burning insulation. The immediate response should be to turn the master switch "OFF." Then close off ventilating air as much as practicable to reduce the chances of a sustained fire. If an oxygen system is available in the aircraft and dense smoke makes breathing difficult, occupants should use oxygen masks until the smoke clears.

If electrical power is indispensable for the flight, an attempt may be made to identify and cut off the defective circuit as follows:

- (1) Master Switch -- "OFF."
- (2) All other switches (except ignition switch) -- "OFF."
- (3) Check condition of circuit breakers to identify faulty circuit if possible. Leave faulty circuit deactivated.
- (4) Master Switch -- "ON."
- (5) Select switches "ON" successively, permitting a short time delay to elapse after each switch is turned on until the short circuit is localized.
- (6) Make sure fire is completely extinguished before opening vents.

## FLIGHT IN ICING CONDITIONS.

Although flying in known icing conditions is prohibited, an unexpected icing encounter should be handled as follows:

- (1) Turn pitot heat switch "ON" (if installed).
- (2) Turn back or change altitude to obtain an outside air temperature that is less conducive to icing.
- (3) Pull cabin heater control full out and rotate defroster control clockwise to obtain windshield defroster airflow.
- (4) Increase engine speed to minimize ice build-up on propeller blades.
- (5) Watch for signs of carburetor air filter ice and apply carburetor heat as required. An unexplained loss in manifold pressure could be caused by carburetor ice or air intake filter ice.
- (6) Plan a landing at the nearest airport. With an extremely rapid ice build-up, select a suitable "off airport" landing site.
- (7) With an ice accumulation of one-quarter inch or more on the wing leading edges, be prepared for significantly higher stall speed.
- (8) Leave wing flaps retracted. With a severe ice build-up on the horizontal tail, the change in wing airflow direction caused by wing flap extension could result in a loss of elevator effectiveness.
- (9) Open left window and, if practical, scrape ice from a portion of the windshield for visibility in the landing approach.
- (10) Perform a landing approach using a forward slip, if necessary, for improved visibility.
- (11) Approach at 80 to 90 MPH, depending upon the amount of ice accumulation.
- (12) Perform a landing in level attitude.

# Section IV

## OPERATING LIMITATIONS

### OPERATIONS AUTHORIZED.

Your Cessna exceeds the requirements for airworthiness as set forth by the United States Government, and is certificated under FAA Type Certificate No. 3A13 as Cessna Model No. 182P.

The airplane may be equipped for day, night, VFR, or IFR operation. Your Cessna Dealer will be happy to assist you in selecting equipment best suited to your needs.

Your airplane must be operated in accordance with all FAA-approved markings and placards in the airplane. If there is any information in this section which contradicts the FAA-approved markings and placards, it is to be disregarded.

### MANEUVERS—NORMAL CATEGORY.

The airplane is certificated in the normal category. The normal category is applicable to airplanes intended for non-aerobatic operations. These include any maneuvers incidental to normal flying, stalls (except whip stalls) and turns in which the angle of bank is not more than 60°. In connection with the foregoing, the following gross weight and flight load factors apply:

Gross Weight . . . . . 2950 lbs

Flight Load Factor:

\*Flaps Up . . . . . +3.8     -1.52  
\*Flaps Down . . . . . +2.0

\*The design load factors are 150% of the above, and in all cases, the structure meets or exceeds design loads.

## AIRSPEED LIMITATIONS (CAS).

The following is a list of the certificated calibrated airspeed (CAS) limitations for the airplane.

|  |         |
|--|---------|
| Never Exceed Speed (glide or dive, smooth air) . . . . . | 198 MPH |
| Maximum Structural Cruising Speed . . . . .              | 160 MPH |
| Maximum Speed, Flaps Extended                            |         |
| Flaps 10° . . . . .                                      | 160 MPH |
| Flaps 10° - 40° . . . . .                                | 110 MPH |
| *Maneuvering Speed . . . . .                             | 126 MPH |

\*The maximum speed at which you may use abrupt control travel.

## AIRSPEED INDICATOR MARKINGS.

The following is a list of the certificated calibrated airspeed markings (CAS) for the airplane.

|  |                          |
|--|--------------------------|
| Never Exceed (glide or dive, smooth air) . . . . . | 198 MPH (red line)       |
| Caution Range . . . . .                            | 160-198 MPH (yellow arc) |
| Normal Operating Range . . . . .                   | 68-160 MPH (green arc)   |
| Flap Operating Range . . . . .                     | 63-110 MPH (white arc)   |

## ENGINE OPERATION LIMITATIONS.

|                           |                     |
|---------------------------|---------------------|
| Power and Speed . . . . . | 230 BHP at 2600 RPM |
|---------------------------|---------------------|

## ENGINE INSTRUMENT MARKINGS.

### OIL TEMPERATURE GAGE.

|                                  |                   |
|----------------------------------|-------------------|
| Normal Operating Range . . . . . | Green Arc         |
| Do Not Exceed . . . . .          | 225° F (red line) |

**OIL PRESSURE GAGE.**

Idling Pressure . . . . . 10 psi (red line)  
Normal Operating Range . . . . . 30-60 psi (green arc)  
Maximum Pressure . . . . . 100 psi (red line)

**FUEL QUANTITY INDICATORS.**

Empty . . . . . E (red line)  
(2.5 gallons unusable each tank in normal flight maneuvers  
with fuel selector valve on "BOTH.")

**CYLINDER HEAD TEMPERATURE GAGE.**

Normal Operating Range . . . . . 200-460°F (green arc)  
Do Not Exceed . . . . . 460°F (red line)

**TACHOMETER.**

Normal Operating Range . . . . . 2200-2450 RPM (green arc)  
Do Not Exceed (Engine rated speed) . . . . . 2600 RPM (red line)

**MANIFOLD PRESSURE GAGE.**

Normal Operating Range . . . . . .15-23 in. Hg (green arc)

**CARBURETOR AIR TEMPERATURE GAGE (OPT).**

Icing Range . . . . . -15° to 5°C (yellow arc)

**SUCTION GAGE (GYRO SYSTEM).**

Normal Operating Range . . . . . 4.6-5.4 in. Hg (green arc)

**WEIGHT AND BALANCE.**

The following information will enable you to operate your Cessna within the prescribed weight and center of gravity limitations. To figure the weight and balance for your particular airplane, use the Sample Problem, Loading Graph, and Center of Gravity Moment Envelope as follows:

Take the licensed empty weight and moment from the Weight and Balance and Installed Equipment Data sheet (or changes noted on FAA Form 337) carried in your airplane, and write them down in the column titled "YOUR AIRPLANE" on the Sample Loading Problem.

#### NOTE

The Weight and Balance and Installed Equipment Data sheet is included in the aircraft file. In addition to the licensed empty weight and moment noted on this sheet, the c. g. arm (fuselage station) is also shown, but need not be used on the Sample Loading Problem. The moment shown on the sheet must be divided by 1000 and this value used as the moment/1000 on the loading problem.

Use the Loading Graph to determine the moment/1000 for each additional item to be carried; then list these on the loading problem.

#### NOTE

Loading Graph information is based on seats positioned for average occupants and baggage loaded in the center of the baggage area. For other than average loading situations, the Sample Loading Problem lists fuselage stations for these items to indicate their forward and aft c. g. range limitation (seat travel or baggage area limitation). Additional moment calculations, based on the actual weight and c. g. arm (fuselage station) of the item being loaded, must be made if the position of the load is different from that shown on the Loading Graph.

Total the weights and moments/1000 and plot these values on the Center of Gravity Moment Envelope to determine whether the point falls within the envelope, and if the loading is acceptable.

### BAGGAGE AND CARGO TIE-DOWN

A nylon baggage net having six tie-down straps is provided as standard equipment to secure baggage in the area aft of the rear seat. Six eyebolts serve as attaching points for the net. Two eyebolts for the forward tie-down straps are mounted on the cabin floor near each sidewall just forward of the baggage door approximately at station 92; two center eyebolts mount on the floor slightly inboard of each sidewall just aft of the baggage door approximately at station 109; the two aft eyebolts secure at the top of the rear baggage wall at station 124. If an optional child's seat is installed, only the center and aft eyebolts will be needed for securing the net in the area remaining behind the seat. A placard on the baggage door defines the weight limitations in the baggage areas.



An optional cargo tie-down kit consisting of nine tie-down attachments is available if it is desired to remove the rear seat (and child's seat, if installed) and utilize the rear cabin area to haul cargo. Two tie-down attachments clamp to the aft end of the two outboard front seat rails and are locked in place by a bolt which must be tightened to a minimum of fifty inch pounds. Seven tie-down attachments bolt to standard attach points in the cabin floor, including three rear seat mounting points. The seven attach points are located as follows: two are located slightly inboard and just aft of the rear door posts approximately at station 69; two utilize the aft outboard mounting points of the rear seat; one utilizes the rearmost mounting point of the aft center attach point for the rear seat approximately at station 84 (a second mounting point is located just forward of this point but is not used); and two are located just forward of the center baggage net tie-down eyebolts approximately at station 108. The maximum allowable cabin floor loading of the rear cabin area is 200 pounds/square foot; however, when items with small or sharp support areas are carried, the installation of a 1/4" plywood floor is recommended to protect the aircraft structure. The maximum rated load weight capacity for each of the seven tie-downs is 140 pounds and for the two seat rail tie-downs is 100 pounds. Rope, strap, or cable used for tie-down should be rated at a minimum of ten times the load weight capacity of the tie-down fittings used. Weight and balance calculations for cargo in the area of the rear seat and the baggage area can be figured on the Loading Graph using the lines labeled "2nd Row Passengers or Cargo" and/or "Baggage or Passengers on Child's Seat."


### LOADING ARRANGEMENTS

\*Pilot or passenger center of gravity on adjustable seats positioned for average occupant. Numbers in parentheses indicate forward and aft limits of occupant center of gravity range.

\*\*Arms measured to the center of the areas shown.


**NOTE:**

The aft baggage wall (approximate station 124) can be used as a convenient interior reference point for determining the location of baggage area fuselage stations.




| SAMPLE AIRPLANE   |  | YOUR AIRPLANE |                          |
|---|--|---------------|--------------------------|
|   |  | Weight (lbs.) | Moment (lb. -ins. /1000) |
| 1. Licensed Empty Weight (Sample Airplane) . . .  |  | 1714          | 60.1                     |
| 2. Oil (12 Qts. - The weight of full oil may be used for all calculations) . . . . .  |  | 22            | -0.3                     |
| 3. Fuel (Standard - 60 Gal. at 6#/Gal.) . . . . .   |  | 360           | 17.3                     |
| 4. Fuel (Long Range - 79 Gal. at 6#/Gal.) . . . . .   |  |               |                          |
| 5. Pilot and Front Passenger (Station 32 to 50) . . . . .   |  | 340           | 12.6                     |
| 5. Second Row Passengers . . . . .  |  | 340           | 25.2                     |
| Cargo Replacing Second Row Seats (Station 65 to 82) . . . . .   |  |               |                          |
| 6. Baggage (Area "A") or Passenger on Child's Seat (Station 82 to 108) 120 Lbs. Max . . . . .   |  | 120           | 11.6                     |
| 7. Baggage - Aft (Area "B") (Station 108 to 124) 80 Lbs. Max . . . . .  |  | 54            | 6.2                      |
| 8. TOTAL WEIGHT AND MOMENT  |  | 2950          | 132.7                    |
| 9. Locate this point (2950 at 132.7) on the center of gravity moment envelope, and since this point falls within the envelope, the loading is acceptable. |  |               |                          |

**SAMPLE LOADING PROBLEM**



- NOTES: (1) Line representing adjustable seats shows pilot and front seat passenger center of gravity on adjustable seats positioned for an average occupant. Refer to the Loading Arrangements diagram for forward and aft limits of occupant c.g. range.  
 (2) Engine Oil: 12 Qts = 22 Lbs. at -0.3 Moment/1000.



# *Section V*

## CARE OF THE AIRPLANE

If your airplane is to retain that new-plane performance and dependability, certain inspection and maintenance requirements must be followed. It is wise to follow a planned schedule of lubrication and preventive maintenance based on climatic and flying conditions encountered in your locality.

Keep in touch with your Cessna Dealer, and take advantage of his knowledge and experience. He knows your airplane and how to maintain it. He will remind you when lubrications and oil changes are necessary, and about other seasonal and periodic services.

## GROUND HANDLING.

The airplane is most easily and safely maneuvered by hand with the tow-bar attached to the nose wheel. When towing with a vehicle, do not exceed the nose gear turning angle of  $29^{\circ}$  either side of center, or damage to the gear will result. If the airplane is towed or pushed over a rough surface during hangaring, watch that the normal cushioning action of the nose strut does not cause excessive vertical movement of the tail and the resulting contact with low hangar doors or structure. A flat nose tire or deflated strut will also increase tail height.

## MOORING YOUR AIRPLANE.

Proper tie-down procedure is your best precaution against damage to your parked airplane by gusty or strong winds. To tie down your airplane securely, proceed as follows:

- (1) Set the parking brake and install the control wheel lock.
- (2) Install a surface control lock over the fin and rudder.
- (3) Tie sufficiently strong ropes or chains (700 pounds tensile strength) to the wing and tail-down fittings, and secure each rope to a ramp tie-down.
- (4) Tie a sufficiently strong rope to the nose gear torque link and secure it to a ramp tie-down.
- (5) Install a pitot tube cover.

## WINDSHIELD-WINDOWS.

The plastic windshield and windows should be cleaned with an aircraft windshield cleaner. Apply the cleaner sparingly with soft cloths, and rub with moderate pressure until all dirt, oil scum and bug stains are removed. Allow the cleaner to dry, then wipe it off with soft flannel cloths.

If a windshield cleaner is not available, the plastic can be cleaned with soft cloths moistened with Stoddard solvent to remove oil and grease.

### NOTE

Never use gasoline, benzine, alcohol, acetone, carbon tetrachloride, fire extinguisher or anti-ice fluid, lacquer thinner or glass cleaner to clean the plastic. These materials will attack the plastic and may cause it to craze.

Follow by carefully washing with a mild detergent and plenty of water. Rinse thoroughly, then dry with a clean moist chamois. Do not rub the plastic with a dry cloth since this builds up an electrostatic charge which attracts dust. Waxing with a good commercial wax will finish the cleaning job. A thin, even coat of wax, polished out by hand with clean soft flannel cloths, will fill in minor scratches and help prevent further scratching.

Do not use a canvas cover on the windshield unless freezing rain or sleet is anticipated since the cover may scratch the plastic surface.

## ALUMINUM SURFACES.

The clad aluminum surfaces of your Cessna may be washed with clear water to remove dirt; oil and grease may be removed with gasoline, naphtha, carbon tetrachloride or other non-alkaline solvents. Dulled aluminum surfaces may be cleaned effectively with an aircraft aluminum polish.

After cleaning, and periodically thereafter, waxing with a good automotive wax will preserve the bright appearance and retard corrosion. Regular waxing is especially recommended for airplanes operated in salt water areas as a protection against corrosion.

## **PAINTED SURFACES.**

The painted exterior surfaces of your new Cessna have a durable, long lasting finish and, under normal conditions, require no polishing or buffing. Approximately 15 days are required for the paint to cure completely; in most cases, the curing period will have been completed prior to delivery of the airplane. In the event that polishing or buffing is required within the curing period, it is recommended that the work be done by someone experienced in handling uncured paint. Any Cessna Dealer can accomplish this work.

Generally, the painted surfaces can be kept bright by washing with water and mild soap, followed by a rinse with water and drying with cloths or a chamois. Harsh or abrasive soaps or detergents which cause corrosion or scratches should never be used. Remove stubborn oil and grease with a cloth moistened with Stoddard solvent.

Waxing is unnecessary to keep the painted surfaces bright. However, if desired, the airplane may be waxed with a good automotive wax. A heavier coating of wax on the leading edges of the wings and tail and on the engine nose cap and propeller spinner will help reduce the abrasion encountered in these areas.

When the airplane is parked outside in cold climates and it is necessary to remove ice before flight, care should be taken to protect the painted surfaces during ice removal with chemical liquids. A 50-50 solution of isopropyl alcohol and water will satisfactorily remove ice accumulations without damaging the paint. A solution with more than 50% alcohol is harmful and should be avoided. While applying the de-icing solution, keep it away from the windshield and cabin windows since the alcohol will attack the plastic and may cause it to craze.

## **PROPELLER CARE.**

Preflight inspection of propeller blades for nicks, and wiping them occasionally with an oily cloth to clean off grass and bug stains will assure long, trouble-free service. Small nicks on the propeller, particularly near the tips and on the leading edges, should be dressed out as soon as possible since these nicks produce stress concentrations, and if ignored, may result in cracks. Never use an alkaline cleaner on the blades; remove grease and dirt with carbon tetrachloride or Stoddard solvent.

## **INTERIOR CARE.**

To remove dust and loose dirt from the upholstery and carpet, clean the interior regularly with a vacuum cleaner.

Blot up any spilled liquid promptly with cleansing tissue or rags. Don't pat the spot; press the blotting material firmly and hold it for several seconds. Continue blotting until no more liquid is taken up. Scrape off sticky materials with a dull knife, then spot-clean the area.

Oily spots may be cleaned with household spot removers, used sparingly. Before using any solvent, read the instructions on the container and test it on an obscure place on the fabric to be cleaned. Never saturate the fabric with a volatile solvent; it may damage the padding and backing materials.

Soiled upholstery and carpet may be cleaned with a foam-type detergent, used according to the manufacturer's instructions. Keep the foam as dry as possible and remove it with a vacuum cleaner, to minimize wetting the fabric.

If your airplane is equipped with leather seating, cleaning of the seats is accomplished using a soft cloth or sponge dipped in mild soap suds. The soap suds, used sparingly, will remove traces of dirt and grease. The soap should be removed with a clean damp cloth.

The plastic trim, headliner, instrument panel and control knobs need only be wiped off with a damp cloth. Oil and grease on the control wheel and control knobs can be removed with a cloth moistened with Stoddard solvent. Volatile solvents, such as mentioned in paragraphs on care of the windshield, must never be used since they soften and craze the plastic.

## **FLYABLE STORAGE.**

Aircraft placed in non-operational storage for a maximum of 30 days or those which receive only intermittent operational use for the first 25 hours are considered in flyable storage status. Every seventh day during these periods, the propeller should be rotated by hand through five revolutions. This action "limbers" the oil and prevents any accumulation of corrosion on engine cylinder walls.

### **IMPORTANT**

For maximum safety, check that the ignition switch is



"OFF," the throttle is closed, the mixture control is in the idle cut-off position, and the airplane is secured before rotating the propeller by hand. Do not stand within the arc of the propeller blades while turning the propeller.

After 30 days, the aircraft should be flown for 30 minutes or a ground runup should be made just long enough to produce an oil temperature within the lower green arc range. Excessive ground runup should be avoided.

Engine runup also helps to eliminate excessive accumulations of water in the fuel system and other air spaces in the engine. Keep fuel tanks full to minimize condensation in the tanks. Keep the battery fully charged to prevent the electrolyte from freezing in cold weather. If the aircraft is to be stored temporarily, or indefinitely, refer to the Service Manual for proper storage procedures.

## **INSPECTION SERVICE AND INSPECTION PERIODS.**

With your airplane you will receive a Customer Care Program book. Coupons attached to the Program book entitle you to an initial inspection and the first 100-hour inspection at no charge. If you take delivery from your Dealer, he will perform the initial inspection before delivery of the airplane to you. If you pick up the airplane at the factory, plan to take it to your Dealer reasonably soon after you take delivery on it. This will permit him to check it over and to make any minor adjustments that may appear necessary. Also, plan an inspection by your Dealer at 100 hours or 180 days, whichever comes first. This inspection also is performed by your Dealer for you at no charge. While these important inspections will be performed for you by any Cessna Dealer, in most cases you will prefer to have the Dealer from whom you purchased the airplane accomplish this work.

Federal Aviation Regulations require that all airplanes have a periodic (annual) inspection as prescribed by the administrator, and performed by a person designated by the administrator. In addition, 100-hour periodic inspections made by an "appropriately-rated mechanic" are required if the airplane is flown for hire. The Cessna Aircraft Company recommends the 100-hour periodic inspection for your airplane. The procedure for this 100-hour inspection has been carefully worked out by the factory and is followed by the Cessna Dealer Organization. The complete familiarity of the Cessna Dealer Organization with Cessna

equipment and with factory-approved procedures provides the highest type of service possible at lower cost.

## **AIRCRAFT FILE.**

There are miscellaneous data, information and licenses that are a part of the aircraft file. The following is a check list for that file. In addition, a periodic check should be made of the latest Federal Aviation Regulations to ensure that all data requirements are met.

A. To be displayed in the aircraft at all times:

- (1) Aircraft Airworthiness Certificate (FAA Form 8100-2).
- (2) Aircraft Registration Certificate (FAA Form 8050-3).
- (3) Aircraft Radio Station License, if transmitter installed (FCC Form 556).

B. To be carried in the aircraft at all times:

- (1) Weight and Balance, and associated papers (latest copy of the Repair and Alteration Form, FAA Form 337, if applicable).
- (2) Aircraft Equipment List.

C. To be made available upon request:

- (1) Aircraft Log Book.
- (2) Engine Log Book.

### **NOTE**

Cessna recommends that these items, plus the Owner's Manual, Power Computer, Pilot's Check List, Customer Care Program book and Customer Care Card, be carried in the aircraft at all times.

Most of the items listed are required by the United States Federal Aviation Regulations. Since the regulations of other nations may require other documents and data, owners of exported aircraft should check with their own aviation officials to determine their individual requirements.

## **MAA PLATE/FINISH AND TRIM PLATE.**

Information concerning the Type Certificate Number (TC), Produc-

tion Certificate Number (PC), Model Number and Serial Number of your particular aircraft can be found on the MAA (Manufacturers Aircraft Association) plate located on the left forward doorpost.

A Finish and Trim Plate contains a code describing the interior color scheme and exterior paint combination of the aircraft. The code may be used in conjunction with an applicable Parts Catalog if finish and trim information is needed. This plate is located at the bottom of the left forward door post.

# LUBRICATION AND SERVICING PROCEDURES

Specific servicing information is provided here for items requiring daily attention. A Servicing Intervals Check List is included to inform the pilot when to have other items checked and serviced.

## DAILY

### FUEL TANK FILLERS:

Service after each flight with 80/87 minimum grade fuel. The capacity of each tank is 32.5 gallons. When optional long range fuel tanks are installed, the capacity of each tank is 42.0 gallons. (To ensure maximum fuel capacity during refueling, place the fuel selector valve handle in either the "LEFT" or "RIGHT" position to prevent cross-feeding.)

### FUEL STRAINER:

On first flight of day and after each refueling, pull out strainer drain knob for about four seconds to clear fuel strainer of possible water and sediment. Check strainer drain closed. If water is observed, there is a possibility that the wing tank sumps contain water. Thus, the wing tank sump drain plugs and fuel selector valve drain plug should be removed to check for the presence of water.

### OIL FILLER:

When preflight check shows low oil level, service with aviation grade engine oil; SAE 50 above 40°F and SAE 10W30 or SAE 30 below 40°F. (Multi-viscosity oil with a range of SAE 10W30 is recommended for improved starting in cold weather.) Detergent or dispersant oil, conforming to Continental Motors Specification MHS-24A, must be used. Your Cessna Dealer can supply approved brands of oil.

### NOTE

Your Cessna was delivered from the factory with a corrosion preventive aircraft engine oil. If oil must be added during the first 25 hours, use only aviation grade straight mineral oil (non-detergent) conforming to Specification No. MIL-L-6082.

# LUBRICATION AND SERVICING PROCEDURES

## DAILY (Continued)

### OIL DIPSTICK:

Check oil level before each flight. Do not operate on less than 9 quarts. To minimize loss of oil through breather, fill to 10 quart level for normal flights of less than 3 hours. For extended flight, fill to 12 quarts. If optional oil filter is installed, one additional quart is required when the filter element is changed.

### OXYGEN CYLINDER AND FILLER VALVE (OPT):

Check oxygen pressure gage for anticipated requirements before each flight. Use filler valve on left side of rear baggage compartment wall to refill cylinder with aviator's breathing oxygen (Spec. No. MIL-O-27210). Maximum pressure (cylinder temperature stabilized after filling), 1800 psi at 70° F. Refer to page 7-10 for filling pressures.

# SERVICING INTERVALS CHECK LIST

## FIRST 25 HOURS

ENGINE OIL SUMP AND OIL FILTER -- After first 25 hours of operation, drain engine oil sump and clean the oil pressure screen. If an optional oil filter is installed, change filter element at this time. Refill sump with straight mineral oil (non-detergent) and use until a total of 50 hours has accumulated or oil consumption has stabilized; then change to detergent oil.

## EACH 50 HOURS

BATTERY -- Check and service. Check more often (at least every 30 days) if operating in hot weather.

ENGINE OIL SUMP AND OIL FILTER -- Change engine oil and replace filter element. If optional oil filter is not installed, change oil and clean the oil pressure screen every 25 hours. Change engine oil at least every four months even though less than the recommended hours have accumulated. Reduce periods for prolonged operation in dusty areas, cold climates, or when short flights and long idle periods result in sludging conditions.

CARBURETOR AIR FILTER -- Clean or replace. Under extremely dusty conditions, daily maintenance of the filter is recommended.

NOSE GEAR TORQUE LINKS -- Lubricate. When operating under dusty conditions, more frequent lubrication is recommended.

## EACH 100 HOURS

SPARK PLUGS -- Clean, test and regap.

FUEL STRAINER -- Disassemble and clean.

FUEL TANK SUMP DRAIN PLUGS -- Remove and drain.

FUEL SELECTOR VALVE DRAIN PLUG -- Remove and drain.

# SERVICING INTERVALS CHECK LIST

## EACH 100 HOURS (Continued)

SHIMMY DAMPENER -- Refer to Service Manual for detailed instructions on checking and filling.

BRAKE MASTER CYLINDERS -- Check and fill.

SUCTION RELIEF VALVE INLET FILTER (OPT) -- Clean.

## EACH 500 HOURS

WHEEL BEARINGS -- Lubricate at first 100 hours and at 500 hours thereafter. Reduce lubrication interval to 100 hours when operating in dusty or seacoast areas, during periods of extensive taxiing, or when numerous take-offs and landings are made.

VACUUM SYSTEM AIR FILTER (OPT) -- Replace filter element. Replace sooner if suction gage reading drops to 4.6 in. Hg.

## AS REQUIRED

NOSE GEAR SHOCK STRUT -- Keep filled with hydraulic fluid and inflated with air to 55-60 psi.

### ADDITIONAL SERVICE AND TEST REGULATIONS

Servicing Intervals of items in the preceding check list are recommended by The Cessna Aircraft Company. Government regulations may require that additional items be inspected, serviced or tested at specific intervals for various types of flight operations. For these regulations, owners should check with aviation officials in the country where the aircraft is being operated.

## OWNER FOLLOW-UP SYSTEM

---

---

Your Cessna Dealer has an owner follow-up system to notify you when he receives information that applies to your Cessna. In addition, if you wish, you may choose to receive similar notification, in the form of Service Letters, directly from the Cessna Customer Services Department. A subscription form is supplied in your Customer Care Program book for your use, should you choose to request this service. Your Cessna Dealer will be glad to supply you with details concerning these follow-up programs, and stands ready through his Service Department to supply you with fast, efficient, low cost service.

### PUBLICATIONS

Various publications and flight operation aids are furnished in the aircraft when delivered from the factory. These items are listed below.

- OWNER'S MANUALS FOR YOUR  
AIRCRAFT  
ELECTRONICS AND AUTOPILOT
- POWER COMPUTER
- SALES AND SERVICE DEALER DIRECTORY
- DO'S AND DON'TS ENGINE BOOKLET

The following additional publications, plus many other supplies that are applicable to your aircraft, are available from your Cessna Dealer.

- SERVICE MANUALS AND PARTS CATALOGS FOR YOUR  
AIRCRAFT  
ENGINE AND ACCESSORIES  
ELECTRONICS AND AUTOPILOT

Your Cessna Dealer has a current catalog of all available Customer Services Supplies, many of which he keeps on hand. If supplies are not in stock, your Cessna Dealer will be happy to order for you.

---

---



# Section VI

## OPERATIONAL DATA

The operational data charts on the following pages are presented for two purposes; first, so that you may know what to expect from your airplane under various conditions, and second, to enable you to plan your flights in detail and with reasonable accuracy.

The data in the charts has been compiled from actual flight tests with the airplane and engine in good condition and using average piloting techniques. Note also that the range charts make no allowances for wind, navigational errors, warm-up, take-off, climb, etc. You must estimate these variables for yourself and make allowances accordingly. Speeds shown in the Cruise Performance charts reflect performance of the Skylane configuration; these speeds are 2 to 3 MPH faster than the Model 182.

Remember that the charts contained herein are based on standard day conditions. For more precise power, fuel consumption, and endurance information, consult the Power Computer supplied with your aircraft. With the Power Computer you can easily take into account temperature variations from standard at any flight altitude.

### AIRSPED CORRECTION TABLE

|                       |     |    |    |     |     |     |     |     |     |
|-----------------------|-----|----|----|-----|-----|-----|-----|-----|-----|
| FLAPS UP              | IAS | 60 | 80 | 100 | 120 | 140 | 160 | 180 | --- |
|                       | CAS | 68 | 83 | 101 | 119 | 139 | 158 | 177 | --- |
| FLAPS DOWN<br>20°-40° | IAS | 40 | 50 | 60  | 70  | 80  | 90  | 100 | 110 |
|                       | CAS | 55 | 60 | 66  | 74  | 83  | 92  | 102 | 111 |

Figure 6-1.

## STALL SPEEDS - MPH CAS

|                              |                  | ANGLE OF BANK |     |    |
|------------------------------|------------------|---------------|-----|----|
| CONDITION                    | 0°               | 30°           | 60° |    |
| 2950 LBS.<br>GROSS<br>WEIGHT | <b>FLAPS UP</b>  | 64            | 69  | 91 |
|                              | <b>FLAPS 20°</b> | 59            | 63  | 83 |
|                              | <b>FLAPS 40°</b> | 57            | 61  | 81 |

**POWER OFF - AFT CG**

Figure 6-2.

# TAKE-OFF DATA

TAKE-OFF DISTANCE WITH 20° FLAPS FROM HARD SURFACE RUNWAY

| GROSS WEIGHT LBS. | IAS @ 50' MPH | HEAD WIND KNOTS | AT SEA LEVEL & 59° F. |                        | AT 2500 FT. & 50° F. |                        | AT 5000 FT. & 41° F. |                        | AT 7500 FT. & 32° F. |                        |
|-------------------|---------------|-----------------|-----------------------|------------------------|----------------------|------------------------|----------------------|------------------------|----------------------|------------------------|
|                   |               |                 | GROUND RUN            | TOTAL TO CLEAR 50' OBS | GROUND RUN           | TOTAL TO CLEAR 50' OBS | GROUND RUN           | TOTAL TO CLEAR 50' OBS | GROUND RUN           | TOTAL TO CLEAR 50' OBS |
| 2950              | 0             | 0               | 705                   | 1350                   | 845                  | 1625                   | 1015                 | 1990                   | 1240                 | 2585                   |
|                   | 10            | 10              | 480                   | 1025                   | 595                  | 1245                   | 725                  | 1550                   | 900                  | 2040                   |
|                   | 20            | 20              | 310                   | 740                    | 385                  | 910                    | 480                  | 1150                   | 610                  | 1545                   |
| 2500              | 0             | 0               | 485                   | 955                    | 575                  | 1120                   | 690                  | 1330                   | 840                  | 1630                   |
|                   | 10            | 10              | 325                   | 710                    | 395                  | 840                    | 475                  | 1005                   | 590                  | 1255                   |
|                   | 20            | 20              | 195                   | 490                    | 245                  | 590                    | 300                  | 720                    | 380                  | 915                    |
| 2000              | 0             | 0               | 295                   | 655                    | 350                  | 745                    | 415                  | 855                    | 500                  | 1005                   |
|                   | 10            | 10              | 195                   | 460                    | 225                  | 530                    | 275                  | 620                    | 335                  | 740                    |
|                   | 20            | 20              | 105                   | 305                    | 130                  | 355                    | 160                  | 425                    | 205                  | 515                    |

NOTES: 1. Increase distances 10% for each 25° F above standard temperature for particular altitude.  
 2. For operation on a dry, grass runway, increase distances (both "ground run" and "total to clear 50 ft. obstacle") by 7% of the "total to clear 50 ft. obstacle" figure.

# MAXIMUM RATE-OF-CLIMB DATA

| GROSS WEIGHT LBS. | AT SEA LEVEL & 59° F. |                      | AT 5000 FT. & 41° F. |                      | AT 10,000 FT. & 23° F. |                      | AT 15,000 FT. & 5° F. |                      | AT 20,000 FT. & -12° F. |                      |     |      |    |     |
|-------------------|-----------------------|----------------------|----------------------|----------------------|------------------------|----------------------|-----------------------|----------------------|-------------------------|----------------------|-----|------|----|-----|
|                   | IAS MPH               | RATE OF CLIMB FT/MIN | IAS MPH              | RATE OF CLIMB FT/MIN | IAS MPH                | RATE OF CLIMB FT/MIN | IAS MPH               | RATE OF CLIMB FT/MIN | IAS MPH                 | RATE OF CLIMB FT/MIN |     |      |    |     |
| 2950              | 89                    | 880                  | 1.5                  | 87                   | 665                    | 3.8                  | 85                    | 445                  | 6.8                     | 83                   | 220 | 11.5 | -- | --  |
| 2500              | 87                    | 1210                 | 1.5                  | 85                   | 935                    | 3.2                  | 83                    | 655                  | 5.2                     | 80                   | 380 | 8.2  | 78 | 105 |
| 2000              | 84                    | 1710                 | 1.5                  | 82                   | 1350                   | 2.7                  | 79                    | 995                  | 4.1                     | 76                   | 640 | 5.9  | 74 | 280 |

NOTES: 1. Flaps up, full throttle, 2600 RPM, mixture leaned for smooth operation above 5000 ft.  
 2. Fuel used includes warm-up and take-off allowance.  
 3. For hot weather, decrease rate of climb 30 ft./min. for each 10° F above standard day temperature for particular altitude.

Figure 6-3.

# CRUISE PERFORMANCE

## LEAN MIXTURE

Standard Conditions  $\setminus$  Zero Wind  $\setminus$  Gross Weight- 2950 Pounds

2500 FEET

| RPM   | MP | % BHP | TAS MPH | GAL/HOUR | 60 GAL(NO RESERVE) |             | 79 GAL(NO RESERVE) |             |
|-------|----|-------|---------|----------|--------------------|-------------|--------------------|-------------|
|       |    |       |         |          | ENDR. HOURS        | RANGE MILES | ENDR. HOURS        | RANGE MILES |
| 2450  | 23 | 76    | 156     | 14.2     | 4.2                | 660         | 5.6                | 870         |
|       | 22 | 72    | 153     | 13.4     | 4.5                | 685         | 5.9                | 900         |
|       | 21 | 68    | 149     | 12.7     | 4.7                | 705         | 6.2                | 925         |
|       | 20 | 63    | 144     | 12.0     | 5.0                | 720         | 6.6                | 950         |
| 2300  | 23 | 71    | 151     | 13.1     | 4.6                | 690         | 6.0                | 910         |
|       | 22 | 67    | 148     | 12.2     | 4.9                | 730         | 6.5                | 960         |
|       | 21 | 62    | 143     | 11.5     | 5.2                | 745         | 6.9                | 980         |
|       | 20 | 59    | 140     | 11.0     | 5.5                | 765         | 7.2                | 1005        |
| 2200  | 23 | 67    | 148     | 12.1     | 5.0                | 735         | 6.5                | 965         |
|       | 22 | 63    | 144     | 11.4     | 5.3                | 760         | 6.9                | 1000        |
|       | 21 | 59    | 140     | 10.8     | 5.6                | 780         | 7.3                | 1025        |
|       | 20 | 55    | 135     | 10.2     | 5.9                | 795         | 7.7                | 1045        |
| *2000 | 20 | 47    | 123     | 8.7      | 6.9                | 850         | 9.1                | 1115        |
|       | 19 | 43    | 117     | 8.2      | 7.3                | 855         | 9.6                | 1125        |
|       | 18 | 39    | 110     | 7.5      | 8.0                | 880         | 10.5               | 1160        |
|       | 17 | 35    | 101     | 7.0      | 8.6                | 865         | 11.3               | 1140        |

\*Power settings in this block represent maximum range settings.

Figure 6-4 (Sheet 1 of 5).

# CRUISE PERFORMANCE

## LEAN MIXTURE

Standard Conditions  $\setminus$  Zero Wind  $\setminus$  Gross Weight- 2950 Pounds

5000 FEET

| RPM   | MP | % BHP | TAS MPH | GAL/HOUR | 60 GAL(NO RESERVE) |             | 79 GAL(NO RESERVE) |             |
|-------|----|-------|---------|----------|--------------------|-------------|--------------------|-------------|
|       |    |       |         |          | ENDR. HOURS        | RANGE MILES | ENDR. HOURS        | RANGE MILES |
| 2450  | 23 | 78    | 160     | 14.5     | 4.1                | 660         | 5.4                | 870         |
|       | 22 | 73    | 157     | 13.6     | 4.4                | 695         | 5.8                | 910         |
|       | 21 | 70    | 153     | 13.0     | 4.6                | 705         | 6.1                | 930         |
|       | 20 | 65    | 149     | 12.2     | 4.9                | 735         | 6.5                | 965         |
| 2300  | 23 | 73    | 157     | 13.4     | 4.5                | 705         | 5.9                | 925         |
|       | 22 | 69    | 152     | 12.6     | 4.8                | 725         | 6.3                | 955         |
|       | 21 | 64    | 148     | 11.9     | 5.0                | 745         | 6.6                | 985         |
|       | 20 | 60    | 144     | 11.2     | 5.4                | 770         | 7.1                | 1015        |
| 2200  | 23 | 68    | 151     | 12.4     | 4.8                | 730         | 6.4                | 960         |
|       | 22 | 64    | 148     | 11.7     | 5.1                | 760         | 6.8                | 1000        |
|       | 21 | 60    | 144     | 11.0     | 5.5                | 785         | 7.2                | 1035        |
|       | 20 | 57    | 139     | 10.5     | 5.7                | 795         | 7.5                | 1045        |
| *2000 | 20 | 48    | 128     | 9.0      | 6.7                | 855         | 8.8                | 1125        |
|       | 19 | 45    | 121     | 8.5      | 7.1                | 855         | 9.3                | 1125        |
|       | 18 | 41    | 114     | 7.9      | 7.6                | 865         | 10.0               | 1140        |
|       | 17 | 37    | 105     | 7.3      | 8.2                | 865         | 10.8               | 1135        |

\*Power settings in this block represent maximum range settings.

Figure 6-4 (Sheet 2 of 5).

# CRUISE PERFORMANCE

## LEAN MIXTURE

Standard Conditions \ Zero Wind \ Gross Weight- 2950 Pounds

**7500 FEET**

| RPM   | MP | % BHP | TAS MPH | GAL/HOUR | 60 GAL(NO RESERVE) |             | 79 GAL(NO RESERVE) |             |
|-------|----|-------|---------|----------|--------------------|-------------|--------------------|-------------|
|       |    |       |         |          | ENDR. HOURS        | RANGE MILES | ENDR. HOURS        | RANGE MILES |
| 2450  | 21 | 71    | 157     | 13.1     | 4.6                | 720         | 6.0                | 945         |
|       | 20 | 67    | 154     | 12.4     | 4.8                | 745         | 6.4                | 980         |
|       | 19 | 62    | 149     | 11.7     | 5.1                | 765         | 6.8                | 1005        |
|       | 18 | 58    | 144     | 11.0     | 5.5                | 785         | 7.2                | 1035        |
| 2300  | 21 | 66    | 153     | 12.2     | 4.9                | 750         | 6.5                | 990         |
|       | 20 | 62    | 149     | 11.6     | 5.2                | 770         | 6.8                | 1015        |
|       | 19 | 58    | 144     | 11.0     | 5.5                | 785         | 7.2                | 1035        |
|       | 18 | 54    | 139     | 10.5     | 5.7                | 795         | 7.5                | 1045        |
| 2200  | 21 | 62    | 149     | 11.4     | 5.3                | 785         | 6.9                | 1035        |
|       | 20 | 58    | 144     | 10.7     | 5.6                | 805         | 7.4                | 1065        |
|       | 19 | 54    | 139     | 10.2     | 5.9                | 820         | 7.7                | 1075        |
|       | 18 | 51    | 133     | 9.7      | 6.2                | 825         | 8.1                | 1085        |
| *2000 | 20 | 50    | 132     | 9.2      | 6.5                | 860         | 8.6                | 1135        |
|       | 19 | 47    | 126     | 8.7      | 6.9                | 870         | 9.1                | 1145        |
|       | 18 | 43    | 118     | 8.1      | 7.4                | 875         | 9.8                | 1150        |
|       | 17 | 39    | 110     | 7.6      | 7.9                | 870         | 10.4               | 1145        |

\*Power settings in this block represent maximum range settings.

Figure 6-4 (Sheet 3 of 5).

# CRUISE PERFORMANCE

## LEAN MIXTURE

Standard Conditions  $\searrow$  Zero Wind  $\swarrow$  Gross Weight- 2950 Pounds  
10,000 FEET

| RPM   | MP | % BHP | TAS MPH | GAL/HOUR | 60 GAL(NO RESERVE) |             | 79 GAL(NO RESERVE) |             |
|-------|----|-------|---------|----------|--------------------|-------------|--------------------|-------------|
|       |    |       |         |          | ENDR. HOURS        | RANGE MILES | ENDR. HOURS        | RANGE MILES |
| 2450  | 19 | 63    | 154     | 11.9     | 5.0                | 775         | 6.6                | 1020        |
|       | 18 | 60    | 149     | 11.2     | 5.4                | 800         | 7.1                | 1050        |
|       | 17 | 55    | 143     | 10.6     | 5.7                | 810         | 7.5                | 1065        |
|       | 16 | 51    | 137     | 10.0     | 6.0                | 820         | 7.9                | 1080        |
| 2300  | 19 | 60    | 149     | 11.1     | 5.4                | 805         | 7.1                | 1060        |
|       | 18 | 56    | 144     | 10.5     | 5.7                | 825         | 7.5                | 1085        |
|       | 17 | 51    | 137     | 9.8      | 6.1                | 840         | 8.1                | 1105        |
|       | 16 | 47    | 130     | 9.2      | 6.5                | 850         | 8.6                | 1115        |
| 2200  | 19 | 56    | 144     | 10.4     | 5.8                | 830         | 7.6                | 1095        |
|       | 18 | 52    | 138     | 9.8      | 6.1                | 845         | 8.1                | 1110        |
|       | 17 | 49    | 132     | 9.3      | 6.5                | 850         | 8.5                | 1120        |
|       | 16 | 45    | 124     | 8.7      | 6.9                | 855         | 9.1                | 1125        |
| *2000 | 19 | 48    | 130     | 8.9      | 6.7                | 875         | 8.9                | 1155        |
|       | 18 | 44    | 123     | 8.4      | 7.1                | 880         | 9.4                | 1155        |
|       | 17 | 40    | 115     | 7.8      | 7.7                | 885         | 10.1               | 1165        |
|       | 16 | 38    | 101     | 7.4      | 8.1                | 820         | 10.7               | 1080        |

\*Power settings in this block represent maximum range settings.

Figure 6-4 (Sheet 4 of 5).

# CRUISE PERFORMANCE

## LEAN MIXTURE

Standard Conditions  $\setminus$  Zero Wind  $\setminus$  Gross Weight- 2950 Pounds

15,000 FEET

| RPM  | MP | % BHP | TAS MPH | GAL/HOUR | 60 GAL(NO RESERVE) |             | 79 GAL(NO RESERVE) |             |
|------|----|-------|---------|----------|--------------------|-------------|--------------------|-------------|
|      |    |       |         |          | ENDR. HOURS        | RANGE MILES | ENDR. HOURS        | RANGE MILES |
| 2450 | 16 | 54    | 145     | 10.4     | 5.8                | 835         | 7.6                | 1100        |
|      | 15 | 50    | 139     | 9.8      | 6.1                | 850         | 8.1                | 1120        |
|      | 14 | 46    | 126     | 9.2      | 6.5                | 820         | 8.6                | 1080        |
| 2300 | 16 | 50    | 139     | 9.6      | 6.2                | 870         | 8.2                | 1145        |
|      | 15 | 47    | 131     | 9.1      | 6.6                | 865         | 8.7                | 1135        |
|      | 14 | 42    | 113     | 8.5      | 7.1                | 800         | 9.3                | 1050        |
| 2200 | 16 | 47    | 131     | 9.1      | 6.6                | 865         | 8.7                | 1135        |
|      | 15 | 44    | 120     | 8.6      | 7.0                | 835         | 9.2                | 1100        |
|      | 14 | 40    | 106     | 8.0      | 7.5                | 795         | 9.9                | 1045        |
| 2000 | 16 | 40    | 106     | 7.8      | 7.7                | 815         | 10.1               | 1075        |
|      | 15 | 37    | 97      | 7.3      | 8.2                | 795         | 10.8               | 1050        |

Figure 6-4 (Sheet 5 of 5).



# LANDING DISTANCE TABLE

## LANDING DISTANCE WITH 40° FLAPS ON HARD SURFACED RUNWAY

| GROSS WEIGHT POUNDS | APPROACH IAS MPH | @ SEA LEVEL & 59° F |                            | @ 2500 FEET & 50° F |                            | @ 5000 FEET & 41° F |                            | @ 7500 FEET & 32° F |                            |
|---------------------|------------------|---------------------|----------------------------|---------------------|----------------------------|---------------------|----------------------------|---------------------|----------------------------|
|                     |                  | GROUND ROLL         | TOTAL TO CLEAR 50 FT. OBS. | GROUND ROLL         | TOTAL TO CLEAR 50 FT. OBS. | GROUND ROLL         | TOTAL TO CLEAR 50 FT. OBS. | GROUND ROLL         | TOTAL TO CLEAR 50 FT. OBS. |
| 2950                | 69               | 590                 | 1350                       | 640                 | 1430                       | 680                 | 1505                       | 740                 | 1595                       |

NOTES: 1. Distances shown are based on zero wind, power off and heavy braking.  
 2. Reduce landing distances 10% for each 5 knots headwind.  
 3. For operation on a dry, grass runway, increase distances (both "ground roll" and "total to clear 50 ft. obstacle") by 20% of the "total to clear 50 ft. obstacle" figure.

Figure 6-5.

# MAXIMUM GLIDE

- SPEED 80 MPH (IAS) —
- PROPELLER WINDMILLING
- FLAPS UP ● ZERO WIND




Figure 6-6.

# *Section VII*

## **OPTIONAL SYSTEMS**

This section contains a description, operating procedures, and performance data (when applicable) for some of the optional equipment which may be installed in your Cessna. Owner's Manual Supplements are provided to cover operation of other optional equipment systems when installed in your airplane. Contact your Cessna Dealer for a complete list of available optional equipment.

### **LONG RANGE FUEL TANKS**

Special wings with long range fuel tanks are available to replace the standard wings and fuel tanks for greater endurance and range. When these tanks are installed, the total usable fuel, for all flight conditions, is 79 gallons.

### **COLD WEATHER EQUIPMENT**

#### **WINTERIZATION KIT AND NON-CONGEALING OIL COOLER.**

For continuous operation in temperatures consistently below 20°F, the Cessna winterization kit and non-congealing oil cooler should be installed to improve engine operation. The winterization kit consists of two shields to partially cover the cowl nose cap opening, one shield to cover the carburetor air intake, and insulation for the crankcase breather line. Once installed, the crankcase breather insulation is approved for permanent use in both cold and hot weather. The non-congealing oil cooler replaces the standard oil cooler and provides improved oil flow through the cooler in cold weather.

## **GROUND SERVICE PLUG RECEPTACLE.**

A ground service plug receptacle may be installed to permit use of an external power source for cold weather starting and during lengthy maintenance work on the airplane electrical system (with the exception of electronic equipment).

### **NOTE**

Electrical power for the airplane electrical circuits is provided through a split bus bar having all electronic circuits on one side of the bus and other electrical circuits on the other side of the bus. When an external power source is connected, a contactor automatically opens the circuit to the electronic portion of the split bus bar as a protection against damage to the transistors in the electronic equipment by transient voltages from the power source. Therefore, the external power source can not be used as a source of power when checking electronic components.

Just before connecting an external power source (generator type or battery cart), the master switch should be turned "ON."

The ground service plug receptacle circuit incorporates a polarity reversal protection. Power from the external power source will flow only if the ground service plug is correctly connected to the airplane. If the plug is accidentally connected backwards, no power will flow to the airplane's electrical system, thereby preventing any damage to electrical equipment.

The battery and external power circuits have been designed to completely eliminate the need to "jumper" across the battery contactor to close it for charging a completely "dead" battery. A special fused circuit in the external power system supplies the needed "jumper" across the contacts so that with a "dead" battery and an external power source applied, turning the master switch "ON" will close the battery contactor.

## **STATIC PRESSURE ALTERNATE SOURCE VALVE.**

A static pressure alternate source valve is available to provide continued operation of the airspeed indicator, altimeter and vertical speed indicator in the event that the static system ports or lines become obstructed.

If erroneous instrument readings are suspected due to water or ice in the static system ports or lines, the static pressure alternate source valve knob should be pulled on, venting the static system to the cabin. However, cabin pressures will vary with open cabin ventilators or windows. The most adverse combinations will result in airspeed and altimeter variations of no more than 6 MPH and 50 feet respectively.

In climb and cruising flight, the airspeed and altimeter will read high. However, in the landing approach (when instrument readings are more important) the instruments will generally read low. Therefore, using the normal published approach speeds and altitudes will result in a slightly faster approach speed and higher approach path than normal, giving an extra margin of safety.

## STATIC DISCHARGERS

If frequent IFR flights are planned, installation of optional wick-type static dischargers is recommended to improve radio communications during flight through dust or various forms of precipitation (rain, freezing rain, snow or ice crystals). Under these conditions, the build-up and discharge of static electricity from the trailing edges of the wings, rudder, elevators, propeller tips and radio antennas can result in loss of usable radio signals on all communications and navigation radio equipment. (Usually the ADF is first to be affected and VHF communication equipment is the last to be affected).

Installation of static dischargers reduces interference from precipitation static, but it is possible to encounter severe precipitation static conditions which might cause the loss of radio signals, even with static dischargers installed. Whenever possible, avoid known severe precipitation areas to prevent loss of dependable radio signals. If avoidance is impractical, minimize airspeed and anticipate temporary loss of radio signals while in these areas.

# RADIO SELECTOR SWITCHES

## RADIO SELECTOR SWITCH OPERATION.

Operation of the radio equipment is normal as covered in the respective radio manuals. When more than one radio is installed, an audio switching system is necessary. Audio switching is accomplished by a series of selector switches located at the top-center of the instrument panel. They are rectangular in shape, internally lighted, and the face of each switch is labeled to define the system it controls. The selector switches have one function when depressed and another function when extended. They are designed to lock when pushed in to the depressed position; they can be extended by pressing full in and allowing them to release to the extended position. Certain combinations of switches are interlocked to prevent more than one system from being utilized at the same time. Depressing one interlocked switch automatically disengages the others. All of the selector switches are lighted anytime the navigation light switch is turned on. When a switch is depressed, its light becomes brighter. This light intensity of a depressed switch can be controlled with the rheostat labeled "DIM AUDIO SW BRT" just below the selector switches. The following information describes the various selector switch functions.

## TRANSMITTER SELECTOR SWITCH.

When two transmitters are installed, the microphone must be switched




Figure 7-1.

to the transmitter the pilot has selected for use. To accomplish this, interlocking transmitter selector switches labeled "TR 1" and "TR 2" are provided. "TR 1" selects the upper transmitter and "TR 2" selects the lower transmitter.

The installation of Cessna radio equipment provides certain audio back-up capabilities and transmitter selector switch functions that the pilot should be familiar with. When the transmitter selector switch labeled "TR 1" or "TR 2" is depressed, the audio amplifier of the corresponding transceiver is utilized to provide the speaker audio for all radios. If the audio amplifier in the selected transceiver fails, as evidenced by loss of speaker audio for all radios, depress the transmitter selector switch for the transceiver not in use. Since an audio amplifier is not utilized for headphones, a malfunctioning amplifier will not affect headphone operation.

## **SPEAKER-PHONE SWITCHES.**

The speaker-phone switches such as "COM 1", "NAV 1" (400 series radios), or "REC 1", "REC 2" (300 series radios) determine whether the output of the receiver in use is fed to the headphones or through the audio amplifier to the speaker. Depress the switch for the desired receiver to obtain speaker operation, or release it if headphone operation is desired.

## **AUTOPILOT-OMNI SWITCH.**

When a Nav-O-Matic autopilot is installed with two compatible omni receivers, two autopilot-omni switches labeled "AP 1" and "AP 2" are utilized. These switches select the omni receiver to be used for the omni course sensing function of the autopilot. This is accomplished by depressing the selector switch corresponding to the receiver which is to be used.

# **BOOM MICROPHONE**

A boom microphone may be mounted near the upper left corner of the windshield. Use of the boom microphone allows radio communication without the necessity of releasing any controls to handle the normal hand microphone. The microphone keying switch is a push button located on the left side of the pilot's control wheel.

## OXYGEN SYSTEM

A four-place oxygen system is available for your airplane. In this system, an oxygen cylinder, located behind the rear baggage compartment wall, supplies the oxygen. Cylinder pressure is reduced to an operating pressure of 70 psi by a pressure regulator attached to the cylinder. A shutoff valve is included as part of the regulator assembly. An oxygen cylinder filler valve is located on the left side of the rear baggage compartment wall. Cylinder pressure is indicated by a pressure gage located in the overhead oxygen console.

Four oxygen outlets are provided; two in the overhead oxygen console and two in the cabin ceiling just above the side windows; one at each of the seating positions. One permanent, microphone-equipped mask is provided for the pilot, and three disposable type masks are provided for the passengers. All masks are the partial-rebreathing type equipped with vinyl plastic hoses and flow indicators.

A remote shutoff valve control, located adjacent to the pilot's oxygen outlet, is used to shut off the supply of oxygen to the system when not in use. The control is mechanically connected to the shutoff valve at the cylinder. With the exception of the shutoff function, the system is completely automatic and requires no manual regulation for change of altitude.

### OXYGEN SYSTEM OPERATION.


Prior to flight, check to be sure that there is an adequate oxygen supply for the trip, by noting the oxygen pressure gage reading. Refer to paragraph OXYGEN DURATION CALCULATION, and to the Oxygen Duration Chart (figure 7-2). Also, check that the face masks and hoses are accessible and in good condition.

Supplemental oxygen should be used by all occupants when cruising above 10,000 feet. As described in the Cessna booklet "Man At Altitude," it is often advisable to use oxygen at altitudes lower than 10,000 feet under conditions of night flying, fatigue, or periods of physiological or emotional disturbances. Also, the habitual and excessive use of tobacco or alcohol will usually necessitate the use of oxygen at less than 10,000 feet.



# OXYGEN DURATION CHART

(48 CUBIC FEET CAPACITY)



NOTE: This chart is based on a pilot with an orange color-coded oxygen line fitting and passengers with green color-coded line fittings.

Figure 7-2.

#### NOTE

For safety reasons, no smoking should be allowed in the aircraft while oxygen is being used.

When ready to use the oxygen system, proceed as follows:

- (1) Select mask and hose.

#### NOTE

The hose provided for the pilot is of a higher flow rate than those for the passengers; it is color-coded with an orange band adjacent to the plug-in fitting. The passenger hoses are color-coded with a green band. If the aircraft owner prefers, he may provide higher flow hoses for all passengers. In any case, it is recommended that the pilot use the larger capacity hose. The pilot's mask is equipped with a microphone to facilitate use of the radio while using oxygen. An adapter cord is furnished with the microphone-equipped mask to mate the mask microphone lead to the auxiliary microphone jack located under the left side of the instrument panel. To connect the oxygen mask microphone, connect the mask lead to the adapter cord and plug the cord into the auxiliary microphone jack. (In aircraft that are equipped with the optional boom microphone, it will be necessary to disconnect the boom microphone lead from the auxiliary microphone jack so that the adapter cord from the oxygen mask microphone can be plugged into the jack.) A switch is incorporated on the left hand control wheel to operate the microphone.

- (2) Attach mask to face and adjust metallic nose strap for snug mask fit.
- (3) Select oxygen outlet located nearest to the seat you are occupying, and plug delivery hose into it. When the oxygen supply is turned on, oxygen will flow continuously at the proper rate of flow for any altitude without any manual adjustments.
- (4) Position oxygen supply control knob "ON."
- (5) Check the flow indicator in the face mask hose. Oxygen is flowing if the indicator is being forced toward the mask.
- (6) Unplug the delivery hose from the outlet coupling when discontinuing use of the oxygen system. This automatically stops the flow of oxygen.
- (7) Position oxygen supply control knob "OFF."

## OXYGEN DURATION CALCULATION.

The Oxygen Duration Chart (figure 7-2) should be used in determining the usable duration (in hours) of the oxygen supply in your airplane. The following procedure outlines the method of finding the duration from the chart.

- (1) Note the available oxygen pressure shown on the pressure gage.
- (2) Locate this pressure on the scale on the left side of the chart, then go across the chart horizontally to the right until you intersect the line representing the number of persons making the flight. After intersecting the line, drop down vertically to the bottom of the chart and read the duration in hours given on the scale.
- (3) As an example of the above procedure, 1400 psi of pressure will safely sustain the pilot only for nearly 6 hours and 15 minutes. The same pressure will sustain the pilot and three passengers for approximately 2 hours and 30 minutes.

### NOTE

The Oxygen Duration Chart is based on a standard configuration oxygen system having one orange color-coded hose assembly for the pilot and green color-coded hoses for the passengers. If orange color-coded hoses are provided for pilot and passengers, it will be necessary to compute new oxygen duration figures due to the greater consumption of oxygen with these hoses. This is accomplished by computing the total duration available to the pilot only (from "PILOT ONLY" line on chart), then dividing this duration by the number of persons (pilot and passengers) using oxygen.

## OXYGEN SYSTEM SERVICING.

The oxygen cylinder, when fully charged, contains approximately 48 cubic feet of oxygen, under a pressure of 1800 psi at 70° F. Filling pressures will vary, however, due to the ambient temperature in the filling area, and because of the temperature rise resulting from compression of the oxygen. Because of this, merely filling to 1800 psi will not result in a properly filled cylinder. Fill to the pressures indicated in the table on the following page for ambient temperature.

### IMPORTANT

Oil, grease, or other lubricants in contact with oxygen create a serious fire hazard, and such contact must be avoided when handling oxygen equipment.

| AMBIENT TEMPERATURE °F | FILLING PRESSURE PSIG | AMBIENT TEMPERATURE °F | FILLING PRESSURE PSIG |
|------------------------|-----------------------|------------------------|-----------------------|
| 0                      | 1600                  | 50                     | 1825                  |
| 10                     | 1650                  | 60                     | 1875                  |
| 20                     | 1700                  | 70                     | 1925                  |
| 30                     | 1725                  | 80                     | 1975                  |
| 40                     | 1775                  | 90                     | 2000                  |

## TRUE AIRSPEED INDICATOR

A true airspeed indicator is available to replace the standard airspeed indicator in your airplane. The true airspeed indicator has a calibrated rotatable ring which works in conjunction with the airspeed indicator dial in a manner similar to the operation of a flight computer.

TO OBTAIN TRUE AIRSPEED, rotate ring until pressure altitude is aligned with outside air temperature in degrees Fahrenheit. Then read true airspeed on rotatable ring opposite airspeed needle.

### NOTE

Pressure altitude should not be confused with indicated altitude. To obtain pressure altitude, set barometric scale on altimeter to "29.92" and read pressure altitude on altimeter. Be sure to return altimeter barometric scale to original barometric setting after pressure altitude has been obtained.

## CESSNA ECONOMY MIXTURE INDICATOR

The Cessna Economy Mixture Indicator is an exhaust gas temperature (EGT) sensing device which visually aids the pilot in obtaining either an efficient maximum power mixture or a desired cruise mixture. Exhaust gas temperature varies with cylinder fuel-to-air ratio, power, and RPM.

### OPERATING INSTRUCTIONS.

The reference EGT must be known before the EGT indicator can be used for take-off and climb. Determine the reference EGT periodically as follows:

- (1) Establish 65% power in level flight at 2450 RPM and part throttle.
- (2) Carefully lean to peak EGT. This is the reference EGT.

| FLIGHT CONDITION     | POWER SETTING              | EGT                            | REMARKS  |
|----------------------|----------------------------|--------------------------------|--|
| TAKE-OFF AND CLIMB   | Full throttle and 2600 RPM | 200° richer than REFERENCE EGT | Use FULL RICH mixture below 3000'  |
| NORMAL CLIMB         | 23" MP and 2450 RPM        | 125° richer than REFERENCE EGT | Above 10,000' use BEST POWER mixture                                       |
| MAXIMUM CRUISE SPEED | 75% or less                | Peak minus 125° F (ENRICHEN)   | BEST POWER mixture, 1 MPH TAS increase and 10% range loss from NORMAL LEAN |
| NORMAL CRUISE        | 75% or less                | Peak minus 75° (ENRICHEN)      | NORMAL LEAN mixture-Owner's Manual and Power Computer performance          |
| MAXIMUM RANGE        | 65% or less                | Peak minus 25° (ENRICHEN)      | 2 MPH TAS loss and 10% range increase from NORMAL LEAN                     |

#### NOTE

Operation at peak EGT is not authorized for continuous operation, except to establish peak EGT for reference at 75% power or less. Operation on the lean side of peak EGT or within 25° of peak EGT is not approved.

The chart on page 7-11 should be used to establish mixture settings in take-off, climb, and cruise conditions.

The yellow index pointer may be set at the reference point, or to a specific point to lean to. It can be positioned manually by turning the screw adjustment on the face of the instrument.

For maximum performance take-off, mixture may be set during static full-power runup, if feasible, or during the ground roll.

#### NOTE

Enrichen mixture during climb if excessive cylinder head temperatures occur.

When leaning the mixture under some cruise conditions, engine roughness may occur before peak EGT is reached. In this case, use the EGT corresponding to the onset of roughness as the reference point instead of peak EGT.

Changes in altitude or power setting require the EGT to be rechecked. Mixture may be controlled in cruise descent by simply enriching to avoid engine roughness. During prolonged descents, maintain sufficient power to keep the EGT needle on scale. In idle descents or landing approaches use full rich mixture. For idle descents or landing approaches at high elevations, the mixture control may be set in a position to permit smooth engine acceleration to maximum power.

# WING LEVELER

A wing leveler may be installed to augment the lateral stability of the airplane. The system uses the Turn Coordinator for roll and yaw sensing. Vacuum pressure, from the engine-driven vacuum pump, is routed from the Turn Coordinator to cylinder-piston servo units attached to the aileron control system. As the airplane deviates from a wing level attitude, vacuum pressure in the servo units is increased or relieved as needed to actuate the ailerons to oppose the deviations.

A separately mounted push-pull control knob, labeled "WING LVLR", is provided on the left side of the instrument panel to turn the system on and off. A "ROLL TRIM" control knob on the Turn Coordinator is used for manual roll trim control to compensate for asymmetrical loading of fuel and passengers, and to optimize system performance in climb, cruise and let-down.

## OPERATING CHECK LIST

### TAKE-OFF.

- (1) "WING LVLR" Control Knob -- Check in off position (full in).

### CLIMB.

- (1) Adjust elevator and rudder trim for climb.
- (2) "WING LVLR" Control Knob -- Pull control knob "ON."
- (3) "ROLL TRIM" Control Knob -- Adjust for wings level attitude.

### CRUISE.

- (1) Adjust power and elevator and rudder trim for level flight.
- (2) "ROLL TRIM" Control Knob -- Adjust as desired.

### DESCENT.

- (1) Adjust power and elevator and rudder trim for desired speed and rate of descent.
- (2) "ROLL TRIM" Control Knob -- Adjust as desired.

## **LANDING.**

- (1) Before landing, push "WING LVLR" control knob full in to the off position.

## **EMERGENCY PROCEDURES**

If a malfunction should occur, the system is easily overpowered with pressure on the control wheel. The system should then be turned off. In the event of partial or complete vacuum failure, the wing leveler will automatically become inoperative. However, the Turn Coordinator used with the wing leveler system will not be affected by loss of vacuum since it is designed with a "back-up" system enabling it to operate from either vacuum or electrical power in the event of failure of one of these sources.

## **OPERATING NOTES**

- (1) The wing leveler system may be overpowered at any time without damage or wear. However, for extended periods of maneuvering it may be desirable to turn the system off.

- (2) It is recommended that the system not be engaged during take-off and landing. Although the system can be easily overpowered, servo forces could significantly alter the manual "feel" of the aileron control, especially should a malfunction occur.

## **FUEL TANK QUICK-DRAIN VALVE KIT**

Two fuel tank quick-drain valves and a fuel sampler cup are available as a kit to facilitate daily draining and inspection of fuel in the main tanks for the presence of water and sediment. The valves replace existing fuel tank drain plugs located at the lower inboard area of the wing. The fuel sampler cup, which may be stowed in the map compartment, is used to drain the valves. The sampler cup has a probe in the center of the cup. When the probe is inserted into the hole in the bottom of the drain valve and pushed upward, fuel flows into the cup to facilitate visual inspection of the fuel. As the cup is removed, the drain valve seats, stopping the flow of fuel.



## OIL QUICK-DRAIN VALVE

An oil quick-drain valve is optionally offered to replace the drain plug in the oil sump drain port. The valve provides a quicker and cleaner method of draining engine oil. To drain the oil with this valve installed, slip a hose over the end of the valve and route the hose to a suitable container, then push upward on the end of the valve until it snaps into the open position. Spring clips will hold the valve open. After draining, use a screwdriver or suitable tool to snap the valve into the extended (closed) position and remove the drain hose.

## CARBURETOR AIR TEMPERATURE GAGE

A carburetor air temperature gage may be installed in the airplane to help detect carburetor icing conditions. The gage is marked with a yellow arc between  $-15^{\circ}$  and  $+5^{\circ}\text{C}$ . The yellow arc indicates the carburetor temperature range where carburetor icing can occur; a placard on the gage reads "KEEP NEEDLE OUT OF YELLOW ARC DURING POSSIBLE ICING CONDITIONS."

Visible moisture or high humidity can cause carburetor ice formation, especially in idle or low power conditions. Under cruising conditions, the formation of ice is usually slow, providing time to detect the loss of manifold pressure caused by the ice. Carburetor icing during take-off is rare since the full-open throttle condition is less susceptible to ice obstruction.

If the carburetor air temperature gage needle moves into the yellow arc during potential carburetor icing conditions, or there is an unexplained drop in manifold pressure, apply full carburetor heat. Upon regaining the original manifold pressure (with heat off), determine by trial and error the minimum amount of carburetor heat required for ice-free operation.

### NOTE

Carburetor heat should not be applied during take-off unless absolutely necessary to obtain smooth engine acceleration (usually in sub-zero temperatures).

