

INTRODUCTION

This section consists of a series of supplements, each covering a single optional system which may be installed in the airplane. Each supplement contains a brief description, and when applicable, operating limitations, emergency and normal procedures, and performance. As listed in the Table of Contents, the supplements are classified under the headings of major configuration variations, general and avionics, and have been provided with reference numbers. Also, the supplements are arranged alphabetically and numerically to make it easier to locate a particular supplement. Other routinely installed items of optional equipment, whose function and operational procedures do not require detailed instructions, are discussed in Section 7.

Limitations contained in the following supplements are FAA approved. Observance of these operating limitations is required by Federal Aviation Regulations.

SUPPLEMENT FLOATPLANE

SECTION 1 GENERAL

INTRODUCTION

This supplement, written especially for operators of the Cessna Hawk XP floatplane, provides information not found in the basic handbook. It contains procedures and data required for safe and efficient operation of the airplane equipped with Edo Model 248B-2440 floats.

Information contained in the basic handbook for the Hawk XP, which is the same as that for the floatplane, is generally not repeated in this supplement.

PERFORMANCE - SPECIFICATIONS

SPEED:

Maximum at Sea Level 118 KNOTS
 Cruise, 80% Power at 6000 Ft 116 KNOTS

CRUISE: Recommended lean mixture with fuel allowance for engine start, taxi, takeoff, climb and 45 minutes reserve.

80% Power at 6000 Ft	Range	395 NM
49 Gallons Usable Fuel	Time	3.4 HRS
80% Power at 6000 Ft	Range	570 NM
66 Gallons Usable Fuel	Time	4.9 HRS
Maximum Range at 10,000 Ft	Range	495 NM
49 Gallons Usable Fuel	Time	5.5 HRS
Maximum Range at 10,000 Ft	Range	705 NM
66 Gallons Usable Fuel	Time	7.9 HRS

RATE OF CLIMB AT SEA LEVEL 870 FPM

SERVICE CEILING 15,500 FT

TAKEOFF PERFORMANCE:

Water Run 1135 FT
 Total Distance Over 50-Ft Obstacle 1850 FT

LANDING PERFORMANCE:

Water Run 660 FT
 Total Distance Over 50-Ft Obstacle 1325 FT

STALL SPEED (CAS):

Flaps Up, Power Off 50 KNOTS
 Flaps Down, Power Off 44 KNOTS

MAXIMUM WEIGHT:

Ramp (Dock) 2558 LBS
 Takeoff or Landing 2550 LBS

STANDARD EMPTY WEIGHT:

Hawk XP 1800 LBS
 Hawk XP II 1827 LBS

MAXIMUM USEFUL LOAD:

Hawk XP 758 LBS
 Hawk XP II 731 LBS

BAGGAGE ALLOWANCE 200 LBS

WING LOADING: Pounds/Sq Ft 14.7

POWER LOADING: Pounds/HP 13.1

FUEL CAPACITY: Total

Standard Tanks 52 GAL.
 Long Range Tanks 68 GAL.

OIL CAPACITY 9 QTS

ENGINE: Teledyne Continental, Fuel Injection IO-360-KB

195 BHP at 2600 RPM

PROPELLER: Constant Speed, Diameter 80 IN.

DESCRIPTIVE DATA

PROPELLER

Propeller Manufacturer: McCauley Accessory Division.

Propeller Model Number: 2A34C203/90DCA-10.

Number of Blades: 2.

Propeller Diameter, Maximum: 80 inches.

Minimum: 78.5 inches.

Propeller Type: Constant speed and hydraulically actuated, with a low pitch setting of 11.3° and high pitch setting of 24.8° (30 inch station).

MAXIMUM CERTIFICATED WEIGHT

Ramp (Dock): 2558 lbs.

Takeoff: 2550 lbs.

Landing: 2550 lbs.

Weight in Baggage Compartment:

Baggage Area 1 - Station 82 to 108: 200 lbs. See note below.

Baggage Area 2 - Station 108 to 142: 50 lbs. See note below.

NOTE

The maximum combined weight capacity for baggage areas 1 and 2 is 200 lbs.

STANDARD AIRPLANE WEIGHTS

Standard Empty Weight, Hawk XP: 1800 lbs.

Hawk XP II: 1827 lbs.

Maximum Useful Load, Hawk XP: 758 lbs.

Hawk XP II: 731 lbs.

SPECIFIC LOADINGS

Wing Loading: 14.7 lbs./sq. ft.

Power Loading: 13.1 lbs./hp.




Figure 1. Three View

SECTION 2 LIMITATIONS

INTRODUCTION

Except as shown in this section, the floatplane operating limitations are the same as those for the Hawk XP landplane when operating in the Normal Category. The limitations in this section apply only to operations of the Model R172K equipped with Edo Model 248B-2440 floats. The limitations included in this section have been approved by the Federal Aviation Administration. Observance of the operating limitations is required by Federal Aviation Regulations.

AIRSPEED LIMITATIONS

Airspeed limitations and their operational significance are shown in figure 2.

	SPEED	KCAS	KIAS	REMARKS
V _{NE}	Never Exceed Speed	161	163	Do not exceed this speed in any operation.
V _{NO}	Maximum Structural Cruising Speed	127	129	Do not exceed this speed except in smooth air, and then only with caution.
V _A	Maneuvering Speed: 2550 Pounds 2300 Pounds 2050 Pounds	102 97 91	104 99 93	Do not make full or abrupt control movements above this speed.
V _{FE}	Maximum Flap Extended Speed: 10° Flaps 10° - 40° Flaps	109 87	110 85	Do not exceed this speed with flaps down.

Figure 2. Airspeed Limitations

AIRSPEED INDICATOR MARKINGS

Airspeed indicator markings are the same as those shown in the basic handbook.

POWER PLANT LIMITATIONS

Propeller Manufacturer: McCauley Accessory Division.
Propeller Model Number: 2A34C203/90DCA-10.
Propeller Diameter, Maximum: 80 inches.
Minimum: 78.5 inches.
Propeller Blade Angle at 30 Inch Station, Low: 11.3°.
High: 24.8°.

WEIGHT LIMITS

Maximum Ramp (Dock) Weight: 2558 lbs.
Maximum Takeoff Weight: 2550 lbs.
Maximum Landing Weight: 2550 lbs.
Maximum Weight in Baggage Compartment:
Baggage Area 1 - Station 82 to 108: 200 lbs. See note below.
Baggage Area 2 - Station 108 to 142: 50 lbs. See note below.

NOTE

The maximum combined weight capacity for baggage areas 1 and 2 is 200 lbs.

NOTE

When floats and the optional child's seat are installed, it is possible to exceed the maximum takeoff weight with all seats occupied and minimum fuel.

CENTER OF GRAVITY LIMITS

Center of Gravity Range:
Forward: 37.0 inches aft of datum at 2100 lbs. or less, with straight line variation to 39.5 inches aft of datum at 2550 lbs.
Aft: 45.5 inches aft of datum at all weights.
Reference Datum: Lower portion of front face of firewall.

MANEUVER LIMITS

The floatplane is certificated in the normal category. The normal category is applicable to aircraft intended for non-aerobatic operations. These include any maneuvers incidental to normal flying, stalls (except whip stalls), lazy eights, chandelles, and steep turns in which the angle of bank is not more than 60°. Aerobatic maneuvers, including spins, are not approved.

FLIGHT LOAD FACTOR LIMITS

Flight Load Factors (Maximum Takeoff Weight - 2550 lbs.):
*Flaps Up +3.8g, -1.52g
*Flaps Down +3.0g

*The design load factors are 150% of the above, and in all cases, the structure meets or exceeds design loads.

OTHER LIMITATIONS

FLAP LIMITATIONS

Approved Takeoff Range: 0° to 20°.
Approved Landing Range: 0° to 40°.

PLACARDS

The following information must be displayed in the form of composite or individual placards in addition to those specified in the basic handbook.

1. In full view of the pilot: (The "DAY-NIGHT-VFR-IFR" entry, shown on the example below, will vary as the airplane is equipped).

The markings and placards installed in this airplane contain operating limitations which must be complied with when operating this airplane in the Normal Category. Other operating limitations which must be complied with when operating this airplane in this category are contained in the Pilot's Operating Handbook and FAA Approved Airplane Flight Manual.

No acrobatic maneuvers, including spins, approved.

Flight into known icing conditions prohibited.

This airplane is certified for the following flight operations as of date of original airworthiness certificate:

DAY—NIGHT—VFR—IFR

2. Near water rudder stowage hook:

WATER RUDDER ALWAYS UP
EXCEPT WATER TAXIING

SECTION 3
EMERGENCY PROCEDURES

INTRODUCTION

Checklist and amplified procedures contained in the basic handbook generally should be followed. The additional or changed procedures specifically required for operation of the Model R172K equipped with Edo Model 248B-2440 floats are presented in this section.

AIRSPEEDS FOR EMERGENCY OPERATION

The speeds listed below should be substituted, as appropriate, for the speeds contained in Section 3 of the basic handbook.

Engine Failure After Takeoff:	
Wing Flaps Up	65 KIAS
Wing Flaps Down 20°	60 KIAS
Maneuvering Speed:	
2550 Lbs	104 KIAS
2300 Lbs	99 KIAS
2050 Lbs	93 KIAS
Maximum Glide:	
2550 Lbs	70 KIAS
2300 Lbs	66 KIAS
2050 Lbs	63 KIAS
Precautionary Landing With Engine Power, Flaps Down . . .	60 KIAS
Landing Without Engine Power:	
Wing Flaps Up	70 KIAS
Wing Flaps Down	60 KIAS

CHECKLIST PROCEDURES

PREFLIGHT INSPECTION

1. Pilot's Operating Handbook and Floatplane Supplement -- AVAILABLE IN THE AIRPLANE.
2. Floats and Struts -- INSPECT for dents, cracks, scratches, etc.
3. Float Compartments -- INSPECT for water accumulation.

NOTE

Remove rubber balls which serve as stoppers on the standpipe in each float compartment and pump out any accumulation of water. Reinstall rubber balls with enough pressure for a snug fit.

4. Water Rudders -- CHECK freedom of movement and security.

BEFORE STARTING ENGINE

1. Water Rudder Operation -- CHECK VISUALLY.
2. Water Rudders -- DOWN for taxiing (retraction handle removed from stowage hook).

TAKEOFF

1. Water Rudders -- UP (retraction handle secured on stowage hook).
2. Wing Flaps -- 0°- 20° (20° preferred).
3. Cowl Flap -- OPEN.
4. Control Wheel -- HOLD FULL AFT.
5. Power -- FULL THROTTLE and 2600 RPM (advance slowly).
6. Mixture -- LEAN FOR LAKE ELEVATION.
7. Control Wheel -- MOVE FORWARD when the nose stops rising to attain planing attitude (on the step).
8. Airspeed -- 45-50 KIAS.
9. Control Wheel -- APPLY LIGHT BACK PRESSURE to lift off.

NOTE

To reduce takeoff water run, the technique of raising one float out of the water may be used. This procedure is described in the amplified procedures in this section.

10. Climb Speed -- 55-65 KIAS (flaps 20°).
60-70 KIAS (flaps UP).
 11. Wing Flaps -- UP after all obstacles are cleared.
- With obstacles ahead, climb at 56 KIAS (flaps 20°).

ENROUTE CLIMB

NORMAL CLIMB

1. Airspeed -- 80-90 KIAS.

MAXIMUM PERFORMANCE CLIMB

1. Airspeed -- 72 KIAS (sea level) to 66 KIAS (10,000 feet).

BEFORE LANDING

1. Water Rudders -- UP.
2. Wing Flaps -- AS DESIRED (0° - 10° below 110 KIAS, 10° - 40° below 85 KIAS).
3. Airspeed -- 65-75 KIAS (flaps UP).
55-65 KIAS (flaps DOWN).

LANDING

1. Touchdown -- SLIGHTLY TAIL LOW.
2. Control Wheel -- HOLD FULL AFT as floatplane decelerates to taxi speed.

NOTE

With forward loadings, a slight nose-down pitch may occur if the elevator is not held full up as floatplane comes down off step.

AFTER LANDING

1. Water Rudders -- DOWN.

SECURING AIRPLANE

1. Fuel Selector Valve -- LEFT TANK or RIGHT TANK to prevent cross-feeding and ensure maximum fuel capacity when refueling.

AMPLIFIED PROCEDURES

TAXIING

Taxi with water rudders down. It is best to limit the engine speed to 800 RPM for normal taxi because water piles up in front of the float bow at higher engine speeds. Taxiing with higher engine RPM may result in engine overheating and will not appreciably increase the taxi speed. In addition, it may lead to water spray striking the propeller tips, causing propeller tip erosion.

During all low speed taxi operations, the elevator should be positioned to keep the float bows out of the water as far as possible. Normally this requires holding the control wheel full aft.

For minimum taxi speed in close quarters, use idle RPM and a single magneto. This procedure is recommended for short periods of time only.

Although taxiing is very simple with the water rudders, it is sometimes necessary to "sail" the floatplane under high wind conditions. In addition to the normal flight controls, the wing flaps and cabin doors will aid in "sailing". Water rudders should be retracted during "sailing".

Rudder trim may be used to reduce rudder pedal forces while taxiing in crosswinds or for extended sailing in one direction.

To taxi great distances, it may be advisable to taxi on the step with the water rudders retracted. Turns on the step from an upwind heading may be made with safety providing they are not too sharp and if ailerons are used counteract any overturning tendency.

TAKEOFF

Start the takeoff by applying full throttle smoothly while holding the control wheel full aft. When the nose stops rising, move the control wheel forward slowly to place the floatplane on the step. Slow control movement and light control pressures produce the best results. Attempts to force the floatplane into the planing attitude will generally result in loss of speed and delay in getting on the step. The floatplane will assume a planing attitude which permits acceleration to takeoff speed, at which time the floatplane will fly off smoothly.

The use of 20° wing flaps throughout the takeoff run is recommended. Upon reaching a safe altitude and airspeed, retract the wing flaps slowly, especially when flying over glassy water because a loss of altitude is not

very apparent over such a surface.

If porpoising is encountered while on the step, apply additional control wheel back pressure to correct the excessively nose-low attitude. If this does not correct the porpoising, immediately reduce power to idle and allow the floatplane to slow to taxi speed, at which time the takeoff can again be initiated.

MAXIMUM PERFORMANCE TAKEOFF

To clear an obstacle after takeoff with 20° wing flaps, use an obstacle clearance speed of 56 KIAS for maximum performance. Takeoff distances are shown in Section 5 for this technique, and on water conditions that are smooth but non-glassy. Under some adverse combinations of takeoff weight, pressure altitude, and air temperature, operation on glassy water may require significantly longer takeoff distances to accelerate to the liftoff speed, and allowance should be made for this.

If liftoff is difficult due to high lake elevation or glassy water, the following procedure is recommended: With the floatplane in the planing attitude, apply full aileron to raise one float out of the water. When one float leaves the water, apply slight elevator back pressure to complete the takeoff. Care must be taken to stop the rising wing as soon as the float is clear of the water, and in crosswinds, raise only the downwind wing. With one float out of the water, the floatplane accelerates to takeoff speed almost instantaneously.

CROSSWIND TAKEOFF

For a crosswind takeoff, start the takeoff run with wing flaps up, ailerons partially deflected into the wind, and water rudders extended for better directional control. Flaps should be extended to 20° and the water rudders retracted when the floatplane is on the step; the remainder of the takeoff is normal. If the floats are lifted from the water one at a time, the downwind float should be lifted first.

ENROUTE CLIMB

When conducting the following climbs, the mixture should be leaned as shown by the fuel flow placard, located on the instrument panel.

NORMAL CLIMB

Normal climbs are conducted at 80-90 KIAS with flaps up, full throttle, and 2600 RPM.

BEST RATE OF CLIMB

The best rate-of-climb speeds range from 72 KIAS at sea level to 66 KIAS at 10,000 feet with flaps up, full throttle, and 2600 RPM.

BEST ANGLE OF CLIMB

If an obstruction ahead requires a steep climb angle, a best angle-of-climb speed should be used with flaps up and maximum power. This speed is 56 KIAS at sea level, increasing to 60 KIAS at 10,000 feet. Climbs at speeds lower than the best rate-of-climb speed should be of short duration to improve engine cooling.

CRUISE

Cruise power settings and corresponding fuel consumption are shown on the Cruise Performance charts, figure 9 in this supplement. Range and endurance information is shown in figures 10 and 11 in this supplement.

LANDING

Normal landings can be made power on or power off using approach speeds of 65-75 KIAS with flaps up and 55-65 KIAS with flaps down.

GLASSY WATER LANDING

With glassy water conditions, flaps should be extended to 20° and enough power used to maintain a low rate of descent (approximately 200 feet per minute). The floatplane should be flown onto the water at this sink rate with no flare attempted since height above glassy water is nearly impossible to judge. Power should be reduced to idle and control wheel back pressure increased upon contacting the surface. As the floatplane decelerates off the step, apply full back pressure on the control wheel. If this glassy water technique is used in conjunction with an obstacle clearance approach, allowance should be made for appreciably longer total distances than are shown in Section 5 to clear a 50-foot obstacle.

CROSSWIND LANDING

The wing-low slip method should be used with the upwind float contacting the surface first.

NOISE ABATEMENT

The certificated noise level for the Model R172K Floatplane at 2550 pounds maximum weight is 75.0 dB(A). No determination has been made by the Federal Aviation Administration that the noise levels of this airplane are or should be acceptable or unacceptable for operation at, into, or out of, any landing area.

SECTION 5 PERFORMANCE

INTRODUCTION

The information presented in the Introduction, Use of Performance Charts, and Sample Problem paragraphs in Section 5 of the basic handbook is applicable to the floatplane. Using this information, and the performance charts in this supplement, complete flight planning may be accomplished.

Cruise performance data in this supplement applies to the Model R172K equipped with Edo Model 248B-2440 floats and is based on a standard day temperature as shown on the charts. The effect of temperature variations from standard can be determined by using the applicable cruise charts in the basic handbook for the landplane.

DEMONSTRATED OPERATING TEMPERATURE

Satisfactory engine cooling has been demonstrated for this floatplane with an outside air temperature 23°C above standard. This is not to be considered as an operating limitation. Reference should be made to Section 2 for engine operating limitations.

AIRSPEED CALIBRATION NORMAL STATIC SOURCE

FLAPS UP												
KIAS	40	50	60	70	80	90	100	110	120	130	140	
KCAS	47	54	62	70	79	88	98	108	118	128	138	
FLAPS 20°												
KIAS	40	50	60	70	80	85	---	---	---	---	---	
KCAS	48	55	63	71	81	86	---	---	---	---	---	
FLAPS 40°												
KIAS	40	50	60	70	80	85	---	---	---	---	---	
KCAS	47	54	63	72	82	87	---	---	---	---	---	

Figure 4. Airspeed Calibration

STALL SPEEDS

CONDITIONS:
Power Off

NOTES:

- Altitude loss during a stall recovery may be as much as 250 feet.
- KIAS values are approximate.

MOST REARWARD CENTER OF GRAVITY

WEIGHT LBS	FLAP DEFLECTION	ANGLE OF BANK							
		0°		30°		45°		60°	
		KIAS	KCAS	KIAS	KCAS	KIAS	KCAS	KIAS	KCAS
2550	UP	44	50	47	54	52	59	62	71
	20°	36	45	38	48	43	54	51	64
	40°	35	44	37	47	42	52	50	62

MOST FORWARD CENTER OF GRAVITY

WEIGHT LBS	FLAP DEFLECTION	ANGLE OF BANK							
		0°		30°		45°		60°	
		KIAS	KCAS	KIAS	KCAS	KIAS	KCAS	KIAS	KCAS
2550	UP	48	53	52	57	57	63	68	75
	20°	43	50	46	54	51	59	61	71
	40°	42	48	45	52	50	57	59	68

Figure 5. Stall Speeds

TAKEOFF DISTANCE MAXIMUM PERFORMANCE

MIXTURE SETTING	
PRESS ALT	GPH
S.L.	16
2000	15
4000	14

CONDITIONS:
Flaps 20°
2600 RPM and Full Throttle
Mixture Set at Placard Fuel Flow
Cowl Flap Open
Zero Wind

NOTE:
Decrease distances 10% for each 9 knots headwind.

WEIGHT LBS	TAKEOFF SPEED KIAS	PRESS ALT FT	0°		10°		20°		30°		40°	
			LIFT OFF 50 FT	AT 50 FT	TOTAL WATER TO CLEAR 50 FT OBS	WATER RUN	TOTAL WATER TO CLEAR 50 FT OBS	WATER RUN	TOTAL WATER TO CLEAR 50 FT OBS	WATER RUN	TOTAL WATER TO CLEAR 50 FT OBS	WATER RUN
2550	49	S.L.	975	1615	1080	1765	1195	1940	1325	2130	1470	2345
		1000	1815	1230	1995	1365	2195	1520	2420	1700	2680	
	56	2000	1265	2050	1405	2265	1570	2505	2760	2775	1975	3095
		3000	1450	2335	1625	2590	1825	2880	2055	3215	2325	3605
		4000	1680	2680	1895	2990	2140	3345	2430	3765	2775	4260

Figure 6. Takeoff Distance

MAXIMUM RATE OF CLIMB

CONDITIONS:
Flaps Up
2600 RPM
Full Throttle
Mixture Set at Placard Fuel Flow
Cowl Flap Open

MIXTURE SETTING	
PRESS ALT	GPH
S.L.	16
4000	14
8000	12
12,000	10

WEIGHT LBS	PRESS ALT FT	CLIMB SPEED KIAS	RATE OF CLIMB - FPM		
			0°C	20°C	40°C
2550	S.L.	72	940	845	750
	2000	71	820	730	635
	4000	69	700	615	525
	6000	68	585	500	415
	8000	67	465	385	305
	10,000	66	350	275	---
	12,000	65	235	160	---

Figure 7. Maximum Rate of Climb

TIME, FUEL, AND DISTANCE TO CLIMB

MAXIMUM RATE OF CLIMB

CONDITIONS:
Flaps Up
2600 RPM
Full Throttle
Mixture Set at Placard Fuel Flow
Cowl Flap Open
Standard Temperature

MIXTURE SETTING	
PRESS ALT	GPH
S.L.	16
4000	14
8000	12
12,000	10

NOTES:

1. Add 1.4 gallons of fuel for engine start, taxi and takeoff allowance.
2. Increase time, fuel and distance by 10% for each 10°C above standard temperature.
3. Distances shown are based on zero wind.

WEIGHT LBS	PRESSURE ALTITUDE FT	TEMP °C	CLIMB SPEED KIAS	RATE OF CLIMB FPM	FROM SEA LEVEL		
					TIME MIN	FUEL USED GALLONS	DISTANCE NM
2550	S.L.	15	72	870	0	0	0
	1000	13	71	820	1	0.3	1
	2000	11	71	770	2	0.6	3
	3000	9	70	720	4	1.0	5
	4000	7	69	670	5	1.3	6
	5000	5	69	620	7	1.7	8
	6000	3	68	570	9	2.0	11
	7000	1	68	520	10	2.4	13
	8000	-1	67	470	12	2.9	15
	9000	-3	66	420	15	3.3	18
	10,000	-5	66	370	17	3.8	22
	11,000	-7	65	320	20	4.3	26
	12,000	-9	65	270	24	4.9	30

Figure 8. Time, Fuel, and Distance to Climb (Sheet 1 of 2)

TIME, FUEL, AND DISTANCE TO CLIMB

NORMAL CLIMB - 85 KIAS

CONDITIONS:
Flaps Up
2600 RPM
Full Throttle
Mixture Set at Placard Fuel Flow
Cowl Flap Open
Standard Temperature

MIXTURE SETTING	
PRESS ALT	GPH
S.L.	16
4000	14
8000	12

- NOTES:
- Add 1.4 gallons of fuel for engine start, taxi and takeoff allowance.
 - Increase time, fuel and distance by 10% for each 8°C above standard temperature.
 - Distances shown are based on zero wind.

WEIGHT LBS	PRESSURE ALTITUDE FT	TEMP °C	RATE OF CLIMB FPM	FROM SEA LEVEL		
				TIME MIN	FUEL USED GALLONS	DISTANCE NM
2550	S.L.	15	810	0	0	0
	1000	13	755	1	0.3	2
	2000	11	700	3	0.7	4
	3000	9	650	4	1.1	6
	4000	7	595	6	1.4	8
	5000	5	540	8	1.9	11
	6000	3	485	10	2.3	14
	7000	1	430	12	2.8	17
8000	-1	375	14	3.3	21	

Figure 8. Time, Fuel, and Distance to Climb (Sheet 2 of 2)

CRUISE PERFORMANCE

PRESSURE ALTITUDE 2000 FEET

CONDITIONS:
2550 Pounds
Recommended Lean Mixture
Cowl Flap Closed

NOTE
For best fuel economy at 70% power or less, operate at 1 GPH leaner than shown in this chart or at peak EGT if an EGT indicator is installed.

RPM	MP	STANDARD TEMPERATURE 11°C		
		% BHP	KTAS	GPH
2600	24	81	114	11.4
	23	76	110	10.7
	22	71	106	10.0
	21	65	102	9.3
2500	25	81	114	11.5
	24	77	111	10.8
	23	72	107	10.2
	22	67	103	9.5
2400	25	76	110	10.8
	24	72	107	10.2
	23	67	103	9.5
	22	63	100	8.9
2300	25	72	107	10.1
	24	67	103	9.5
	23	63	100	8.9
	22	59	96	8.4
2200	25	67	103	9.4
	24	63	99	8.9
	23	59	95	8.3
	22	55	91	7.8
	21	51	87	7.3
	20	47	83	6.8
19	43	77	6.3	

Figure 9. Cruise Performance (Sheet 1 of 6)

CRUISE PERFORMANCE
PRESSURE ALTITUDE 4000 FEET

CONDITIONS:
 2550 Pounds
 Recommended Lean Mixture
 Cowl Flap Closed

NOTE
 For best fuel economy at 70% power or less, operate at 1 GPH leaner than shown in this chart or at peak EGT if an EGT indicator is installed.

RPM	MP	STANDARD TEMPERATURE 7°C		
		% BHP	KTAS	GPH
2600	23	79	114	11.1
	22	73	110	10.4
	21	68	106	9.7
	20	63	101	9.0
2500	24	79	114	11.2
	23	75	111	10.6
	22	70	107	9.9
	21	65	103	9.3
2400	24	74	111	10.5
	23	70	107	9.9
	22	65	103	9.2
	21	61	99	8.6
2300	24	70	107	9.9
	23	65	103	9.3
	22	61	99	8.7
	21	57	95	8.1
2200	24	65	103	9.2
	23	61	99	8.7
	22	57	95	8.1
	21	53	91	7.6
	20	49	86	7.1
19	45	80	6.6	

Figure 9. Cruise Performance (Sheet 2 of 6)

CRUISE PERFORMANCE
PRESSURE ALTITUDE 6000 FEET

CONDITIONS:
 2550 Pounds
 Recommended Lean Mixture
 Cowl Flap Closed

NOTE
 For best fuel economy at 70% power or less, operate at 1 GPH leaner than shown in this chart or at peak EGT if an EGT indicator is installed.

RPM	MP	STANDARD TEMPERATURE 3°C		
		% BHP	KTAS	GPH
2600	23	81	117	11.5
	22	76	114	10.8
	21	71	110	10.1
	20	66	105	9.3
2500	23	77	114	10.9
	22	73	111	10.3
	21	68	107	9.6
	20	63	103	9.0
2400	23	72	110	10.2
	22	68	107	9.6
	21	63	102	9.0
	20	59	98	8.4
2300	23	68	107	9.6
	22	64	103	9.0
	21	59	98	8.4
	20	55	94	7.9
2200	23	63	103	9.0
	22	59	98	8.4
	21	55	94	7.9
	20	51	90	7.4
	19	47	84	6.8
	18	43	78	6.4

Figure 9. Cruise Performance (Sheet 3 of 6)

CRUISE PERFORMANCE
 PRESSURE ALTITUDE 8000 FEET

CONDITIONS:
 2550 Pounds
 Recommended Lean Mixture
 Cowl Flap Closed

NOTE
 For best fuel economy at 70% power or less, operate at 1 GPH leaner than shown in this chart or at peak EGT if an EGT indicator is installed.

		STANDARD TEMPERATURE -1°C		
RPM	MP	% BHP	KTAS	GPH
2600	21	74	114	10.5
	20	69	109	9.8
	19	64	104	9.0
	18	59	99	8.3
2500	21	71	111	10.0
	20	66	107	9.4
	19	61	102	8.7
	18	56	97	8.1
2400	21	65	106	9.3
	20	61	101	8.6
	19	56	97	8.0
	18	52	91	7.5
2300	21	62	102	8.7
	20	57	98	8.2
	19	53	93	7.6
	18	48	87	7.0
2200	21	57	98	8.2
	20	53	93	7.7
	19	49	88	7.1
	18	45	81	6.6

Figure 9. Cruise Performance (Sheet 4 of 6)

CRUISE PERFORMANCE
 PRESSURE ALTITUDE 10,000 FEET

CONDITIONS:
 2550 Pounds
 Recommended Lean Mixture
 Cowl Flap Closed

NOTE
 For best fuel economy at 70% power or less, operate at 1 GPH leaner than shown in this chart or at peak EGT if an EGT indicator is installed.

		STANDARD TEMPERATURE -5°C		
RPM	MP	% BHP	KTAS	GPH
2600	19	67	108	9.4
	18	61	103	8.7
	17	56	97	8.0
	16	51	90	7.3
2500	19	64	106	9.1
	18	59	101	8.4
	17	54	95	7.8
	16	49	87	7.1
2400	19	59	100	8.3
	18	54	95	7.8
	17	49	89	7.2
	16	45	82	6.6
2300	19	55	96	7.9
	18	51	91	7.3
	17	46	84	6.8
2200	19	51	91	7.4
	18	47	85	6.9
	17	43	78	6.4

Figure 9. Cruise Performance (Sheet 5 of 6)

CRUISE PERFORMANCE

PRESSURE ALTITUDE 12,000 FEET

CONDITIONS:
2550 Pounds
Recommended Lean Mixture
Cowl Flap Closed

NOTE
For best fuel economy at 70% power or less, operate at 1 GPH leaner than shown in this chart or at peak EGT if an EGT indicator is installed.

RPM	MP	STANDARD TEMPERATURE -9°C		
		% BHP	KTAS	GPH
2600	18	64	107	9.1
	17	59	102	8.4
	16	53	95	7.7
	15	48	86	7.0
2500	18	62	105	8.8
	17	57	99	8.1
	16	51	92	7.4
	15	45	82	6.7
2400	18	56	99	8.0
	17	52	92	7.5
	16	47	85	6.9
	15	43	77	6.4
2300	18	53	94	7.6
	17	48	88	7.1
	16	44	80	6.5
2200	18	49	89	7.1
	17	45	82	6.6

Figure 9. Cruise Performance (Sheet 6 of 6)

RANGE PROFILE

45 MINUTES RESERVE
49 GALLONS USABLE FUEL

CONDITIONS:
2550 Pounds
Recommended Lean Mixture for Cruise
Standard Temperature
Zero Wind

NOTE:
This chart allows for the fuel used for engine start, taxi, takeoff and climb, and the distance during a normal climb up to 8,000 feet and maximum climb above 8,000 feet.




Figure 10. Range Profile (Sheet 1 of 2)

RANGE PROFILE
45 MINUTES RESERVE
66 GALLONS USABLE FUEL

CONDITIONS:
 2550 Pounds
 Recommended Lean Mixture for Cruise
 Standard Temperature
 Zero Wind

NOTE:
 This chart allows for the fuel used for engine start, taxi, takeoff and climb, and the distance during a normal climb up to 8,000 feet and maximum climb above 8,000 feet.




Figure 10. Range Profile (Sheet 2 of 2)

ENDURANCE PROFILE
45 MINUTES RESERVE
49 GALLONS USABLE FUEL

CONDITIONS:
 2550 Pounds
 Recommended Lean Mixture for Cruise
 Standard Temperature

NOTE:
 This chart allows for the fuel used for engine start, taxi, takeoff and climb, and the time during a normal climb up to 8,000 feet and maximum climb above 8,000 feet.




Figure 11. Endurance Profile (Sheet 1 of 2)

ENDURANCE PROFILE
45 MINUTES RESERVE
66 GALLONS USABLE FUEL

CONDITIONS:
2550 Pounds
Recommended Lean Mixture for Cruise
Standard Temperature

NOTE:
This chart allows for the fuel used for engine start, taxi, takeoff and climb, and the time during a normal climb up to 8,000 feet and maximum climb above 8,000 feet.




Figure 11. Endurance Profile (Sheet 2 of 2)

LANDING DISTANCE
MAXIMUM PERFORMANCE

CONDITIONS:
Flaps 40°
Power Off
Zero Wind

NOTES:

1. Refer to Section 4 for recommended technique if water surface is glassy.
2. Decrease distances 10% for each 9 knots headwind.

WEIGHT LBS	SPEED AT 50 FT KIAS	PRESS ALT FT	0°C		10°C		20°C		30°C		40°C	
			WATER RUN	TOTAL TO CLEAR 50 FT OBS	WATER RUN	TOTAL TO CLEAR 50 FT OBS	WATER RUN	TOTAL TO CLEAR 50 FT OBS	WATER RUN	TOTAL TO CLEAR 50 FT OBS	WATER RUN	TOTAL TO CLEAR 50 FT OBS
2550	60	S.L.	625	1275	650	1310	670	1340	695	1375	715	1410
		1000	650	1310	670	1340	695	1380	720	1415	745	1450
		2000	675	1345	700	1385	720	1415	745	1455	770	1490
		3000	700	1385	725	1420	750	1460	775	1500	800	1535
		4000	725	1420	750	1460	775	1500	805	1545	830	1580

Figure 12. Landing Distance

SECTION 6 WEIGHT & BALANCE

INTRODUCTION

Weight and balance information contained in the basic handbook generally should be used, and will enable you to operate the floatplane within the prescribed weight and center of gravity limitations. The changed information specifically required for operation of the Model R172K equipped with Edo Model 248B-2440 floats is presented in this section.

NOTE

When floats and the optional child's seat are installed, it is possible to exceed the maximum takeoff weight with all seats occupied and minimum fuel.

It is the responsibility of the pilot to ensure that the floatplane is loaded properly.




Figure 13. Center of Gravity Moment Envelope




Figure 14. Center of Gravity Limits



SECTION 7

AIRPLANE & SYSTEMS DESCRIPTIONS

INTRODUCTION

This section contains a description of the modifications and equipment associated specifically with the installation of Edo Model 248B-2440 floats on the Model R172K.

THE FLOATPLANE

The floatplane is identical to the landplane with the following exceptions:

1. Floats, incorporating a water rudder steering system, replace the landing gear. A water rudder retraction handle, connected to the dual water rudders by cables, is located on the cabin floor.
2. Additional fuselage structure is added to support the float installation.
3. An additional structural "V" brace is installed between the top of the front door posts and the cowl deck.
4. The airplane has additional corrosion-proofing and stainless steel cables.
5. The fuel strainer installation is modified for floatplane use.
6. Hoisting provisions are added to the top of the fuselage.
7. Fueling steps and assist handles are mounted on the forward fuselage, and steps are mounted on the wing struts to aid in refueling the airplane.
8. Interconnect springs are added between the rudder and aileron control systems.
9. A heavier rudder trim bungee is added.
10. Two tailcone rudder centering bungees are added.
11. The standard propeller is replaced with a propeller of larger diameter (80 inches).
12. Floatplane placards are added.




Figure 15. Water Rudder Retraction System

WATER RUDDER SYSTEM

Retractable water rudders (figure 15), mounted at the aft end of each float, are connected by a system of cables and springs to the rudder pedals. Normal rudder pedal operation moves the water rudders to provide steering control (figure 16) for taxiing.

A water rudder retraction handle, located on the cabin floor between the front seats, is used to manually raise and lower the water rudders. During takeoff, landing, and in flight, the handle should be secured on the stowage hook located on the cabin floor just aft of the control pedestal. With the handle in this position, the water rudders are up. When the handle is removed from the hook and allowed to move full aft, the water rudders extend to the full down position for taxiing.




Figure 16. Water Rudder Steering System

SECTION 8

AIRPLANE HANDLING, SERVICE & MAINTENANCE

INTRODUCTION

Section 8 of the basic handbook applies, in general, to the floatplane. The following recommended procedures apply specifically to floatplane operation. (Cleaning and maintenance of the floats should be accomplished as suggested in the Edo Corporation Service and Maintenance Manual for Floats.)

MOORING

Proper securing of the floatplane can vary considerably, depending on the type of operation involved and the facilities available. Each operator should use the method most appropriate for his operation. Some of the most common mooring alternatives are as follows:

1. The floatplane can be moored to a buoy, using a yoke tied to the forward float cleats, so that it will freely weathervane into the wind.
2. The floatplane can be secured to a dock using the fore and aft cleats of one float, although this method is generally not recommended unless the water is calm and the floatplane is attended.
3. The floatplane may be removed from the water (by use of a special lift under the spreader bars) and secured by using the wing tie-down rings and float cleats. If conditions permit the floatplane to be beached, ensure that the shoreline is free of rocks or abrasive material that may damage the floats.